



# INSTALLATION MANUAL

## FOR ROTAX® ENGINE TYPE 912 SERIES

Ref. No.: IM-912



**ROTAX® 912 ULS 3** WITH OPTIONS

## **WARNING**

Before starting with engine installation, please read the Installation Manual completely as it contains important safety relevant information.

These technical data and the information embodied therein are the property of BRP-Powertrain GmbH&Co. KG, Austria, acc, BGBl 1984 no. 448, and shall not, without prior written permission of BRP-Powertrain GmbH&Co. KG, be disclosed in whole or in part to third parties. This legend shall be included on any reproduction of these data, in whole or in part. The Manual must remain with the engine/aircraft in case of sale.

Copyright 2009 © - all rights reserved.

ROTAX<sup>®</sup> is a trade mark of BRP-Powertrain GmbH&Co. KG. In the following document the short form of BRP-Powertrain GmbH&Co. KG = BRP-Powertrain is used.

Other product names in this documentation are used purely for ease of identification and may be trademarks of the respective company or owner.

Approval of translation has been done to best knowledge and judgement - in any case the original text in german language is authoritative.

**BRP-Rotax**  
INSTALLATION MANUAL

**1) Table of contents**

<b>1) Table of contents .....</b>	<b>3</b>
<b>2) Index .....</b>	<b>7</b>
<b>3) Preface .....</b>	<b>9</b>
3.1) Remarks .....	9
3.2) Engine serial number .....	9
3.3) ROTAX Authorized Distributors for Aircraft Engines .....	9
<b>4) Safety .....</b>	<b>11</b>
4.1) Repeating symbols .....	11
4.2) Safety information .....	11
4.3) Instruction .....	13
4.4) Technical documentation .....	14
<b>5) List of the effective pages .....</b>	<b>17</b>
<b>6) Table of amendments .....</b>	<b>19</b>
<b>7) Description of design .....</b>	<b>21</b>
7.1) Designation of type .....	21
7.2) Standard engine design .....	21
7.3) Engine components, engine views, definition of main axes .....	24
<b>8) Technical data .....</b>	<b>27</b>
8.1) Operating limits .....	27
8.2) Installation dimensions .....	28
8.3) Weight .....	28
8.4) Centre of gravity of engine and standard equipment .....	29
8.5) Moments of inertia .....	29
<b>9) Preparations for engine installation .....</b>	<b>31</b>
9.1) Transport .....	31
9.2) State of delivery .....	31
9.3) Engine preservation .....	31
9.4) Protective covering .....	32
<b>10) Engine suspension and position .....</b>	<b>33</b>
10.1) Definition of attachment points .....	34
10.2) Permissible fitting positions .....	35
10.3) General directives for engine suspension .....	38
<b>11) Exhaust system .....</b>	<b>39</b>
11.1) Requirements on the exhaust system .....	40
11.2) operating limits .....	41
11.3) General directives for exhaust-system .....	42
11.4) Data for optional components of exhaust system .....	43
<b>12) Cooling system .....</b>	<b>47</b>
12.1) Description of the system .....	47
12.2) Operating Limits .....	48

d04050

# BRP-Rotax

## INSTALLATION MANUAL

12.3)	Coolant types .....	49
12.4)	Check cooling system - Efficiency of the cooling system .....	50
12.4.1)	Measurement of cylinder head temperature and exit temperature .....	50
12.5)	Determination of operating limits, Coolant and necessary modification on radiator installation .....	52
12.6)	Requirements on the cooling system .....	54
12.7)	Size and position of connections .....	55
12.8)	Feasible location of radiator .....	58
12.9)	General directives for the cooling system .....	61
12.10)	Coolant capacity .....	63
12.11)	Cooling air ducting .....	63
12.11.1)	General directives for ducting of the cooling air .....	64
12.12)	Data for optional components of cooling system .....	65
<b>13)</b>	<b>Lubrication system .....</b>	<b>67</b>
13.1)	Description of the system .....	67
13.2)	Limits of operation .....	68
13.3)	Checking of the lubrication system .....	69
13.3.1)	Measuring of the vacuum .....	69
13.3.2)	Measuring of the pressure in the crankcase .....	70
13.4)	Requirements on the oil- and venting lines .....	71
13.5)	Connecting dimensions and location of connections .....	72
13.5.1)	Oil circuit (engine) .....	72
13.5.2)	Oil tank .....	75
13.6)	Feasible position and location of the oil tank .....	76
13.7)	Feasible position and location of the oil cooler .....	77
13.8)	General notes on oil cooler .....	77
13.9)	Filling capacity .....	77
13.10)	Purging of lubrication system .....	78
13.11)	Inspection for correct priming of hydraulic valve tappets .....	79
13.12)	Replacement of components .....	80
13.13)	Data for optional components of oil system .....	81
<b>14)</b>	<b>Fuel system .....</b>	<b>83</b>
14.1)	Description of system .....	83
14.2)	Operating limits .....	85
14.3)	Requirements of the fuel system .....	86
14.4)	Connecting dimensions, location of joints and directives for installation .....	87
14.4.1)	fuel manifold .....	87
14.4.2)	Fuel pressure control .....	88
14.4.3)	Check valve .....	89
<b>15)</b>	<b>Carburetor .....</b>	<b>91</b>
15.1)	Requirements on the carburetor .....	91
15.1.1)	Drainage piping on airbox and drip trays .....	92
15.2)	Connections for Bowden-cable actuation and limit load .....	94
15.3)	Requirements on cable actuation .....	96
15.4)	Requirements on the throttle lever .....	97

d04050

**BRP-Powertrain**  
**INSTALLATION MANUAL**

<b>16) Air intake system .....</b>	<b>99</b>
16.1) Operating limits .....	99
16.2) Requirements on the air intake system .....	100
16.2.1) Requirements on the intake air ducting .....	100
16.2.2) Airfilter .....	100
16.2.3) Airbox .....	101
16.3) Data for optional components of air intake system .....	104
<b>17) Electric system .....</b>	<b>107</b>
17.1) Requirements on circuit wiring .....	107
17.1.1) Electromagnetic compatibility (EMC/EMI) .....	108
17.2) Wiring diagram .....	108
17.3) Technical data and connection of the electric components .....	110
17.3.1) Integrated generator .....	110
17.3.2) Rectifier-regulator .....	110
17.3.3) Electronic modules .....	112
17.3.4) Ignition switches (MAG switch) .....	112
17.3.5) Electric starter .....	114
17.3.6) Starter relay .....	115
17.3.7) External alternator (optional extra) .....	116
17.3.8) Connection of the electric rev-counter (tachometer) .....	118
17.3.9) Battery .....	119
17.3.10) Capacitor (option electric fuel pump) .....	119
17.3.11) Starting equipment at the electronic modules (optional extra) .....	119
<b>18) Propeller drive .....</b>	<b>121</b>
18.1) Technical data .....	121
<b>19) Vacuum pump .....</b>	<b>123</b>
19.1) Technical data .....	123
<b>20) Hydraulic governor for constant speed propeller .....</b>	<b>125</b>
20.1) Technical data .....	125
<b>21) Connections for instrumentation .....</b>	<b>127</b>
21.1) Sensor for cylinder head temperature .....	127
21.2) Sensor for oil temperature .....	128
21.3) Oil pressure sensor .....	129
21.4) Mechanical rev counter (tach drive): .....	130
21.5) Monitoring of the intake manifold pressure .....	131
21.6) Air temperature in the airbox (optional) .....	132
<b>22) Preparations for trial run of engine .....</b>	<b>133</b>

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04050

**BRP-Rotax**  
INSTALLATION MANUAL

## 2) Index

### A

Acceleration 27  
Air intake system 99  
Air temperature in the airbox 132  
Airbox 101  
Airfilter 100  
Attachment points 34  
Auxiliary equipment 22

### B

Bank angle 27  
Battery 119

### C

Carburetor 91  
Coarse filter 86  
Connection of electric rev-counter 118  
Connections (cooling system) 55  
Connections (oil circuit) 72  
Connections carburetor 94  
Connections for instrumentation 127  
Coolant capacity 63  
Cooling system 47  
Critical flight level 27  
Current pages 17  
Cylinder head temperature sensor 127

### D

Definition of main axes 24  
Denomination of cylinders 24  
Description of design 21  
Designation of type 21  
Documentation 14  
Drainage lines (airbox) 101  
Drainage piping (drip tray) 92  
Drip tray 91

### E

Electric fuel pump 87, 89  
Electric starter 114  
Electromagnetic compatibility 108  
Electronic modules 112  
Elektric system 107  
Engine components 24  
Engine serial number 9  
Engine speed 27  
Engine suspension 33, 38  
Engine views 24  
Exhaust system 39  
Expansion tank 55  
External alternator 116

### F

Fine filter 86  
Fitting positions 35  
Fuel filter 86  
Fuel pressure 85  
Fuel pressure control 88  
Fuel system 83

### H

Hydraulic governor for constant speed propeller 125

### I

Ignition switches 112  
Instruction 13  
Instrumentation connection 127  
Intake air ducting 100  
Integrated generator 110

### L

Location of radiator 58  
Lubrication system 67

### M

Main axes 24  
Manifold pressure 27  
Manifold pressure connector 131  
Mechanical rev-counter 130

### O

Oil cooler 77  
Oil lines 71  
Oil pressure 68  
Oil pressure sensor 129  
Oil tank 75, 76  
Oil temperature 68  
On-off switch 112  
Operating limits 27  
Overflow bottle 59

### P

Position of engine 33  
Preface 9  
Preservation (engine) 31  
Propeller drive 121  
Protective covering 32

### R

Rectifier-regulator 110  
Remarks 9  
Rev-counter drive 130

# **BRP-Rotax**

## **INSTALLATION MANUAL**

### **S**

Safety 11  
Safety information 11  
Sensor for oil temperature 128  
Standard engine design 21  
Starter relay 115  
State of delivery 31  
Symbols 11

### **T**

Take-off speed 27  
Technical data 27  
Technical documentation 14  
Temperature in airbox 99  
Throttle lever 97  
Transport 31  
Trial run 133

### **V**

Vacuum pump 123  
Venting line of oil tank 71

### **W**

Water inlet bend 57  
Wiring diagram (electric) 108

d04050



**BRP-Powertrain**  
INSTALLATION MANUAL

### **3) Preface**

In this Manual the installation of all ROTAX 912 Series engines is described.

◆ **NOTE:** ROTAX 912 Series includes 912 A, 912 F, 912 S, 912 UL, 912 ULS and 912 ULSFR.

Before starting with the engine installation, read this Installation Manual carefully. The Manual will provide you with basic information on correct engine installation, a requirement for safe engine operation.

If any passages of the Manual are not completely understood or in case of questions, please, contact an authorized Distribution- or Service Center for ROTAX engines.

|| BRP-Powertrain GmbH & Co KG (hereinafter "BRP-Powertrain") wish you much pleasure and satisfaction flying your aircraft powered by this ROTAX engine.

#### **3.1) Remarks**

This Installation Manual is to acquaint the owner/user of this aircraft engine with basic installation instructions and safety information.

For more detailed information on operation, maintenance, safety- or flight, consult the documentation provided by the aircraft manufacturer and dealer.

For further information on maintenance and spare part service contact the nearest ROTAX distributor (see section 3.3).

#### **3.2) Engine serial number**

On all enquiries or spare parts orders, always indicate the engine serial number, as the manufacturer makes modifications to the engine for further development.

The engine serial number is on the top of the crankcase, magneto side.

#### **3.3) ROTAX Authorized Distributors for Aircraft Engines**

See latest Operators Manual or in the Internet at the official Homepage **[www.rotax-aircraft-engines.com](http://www.rotax-aircraft-engines.com)**.

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04051

### 4) Safety

Although the mere reading of these instructions will not eliminate a hazard, the understanding and application of the information herein will promote the proper installation and use of the engine.

|| The information and components-/system descriptions contained in this Installation Manual are correct at the time of publication. BRP-Powertrain, however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on its products previously manufactured.

|| BRP-Powertrain reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring obligation.

The illustrations in this Installation Manual show the typical construction. They may not represent in full detail or the exact shape of the parts which have the same or similar function.

Specifications are given in the SI metric system with the USA equivalent in parenthesis. Where precise accuracy is not required, some conversions are rounded off for easier use.

#### 4.1) Repeating symbols

This Manual uses the following symbols to emphasize particular information. These indications are important and must be respected.

▲ **WARNING:** Identifies an instruction which, if not followed, may cause serious injury including the possibility of death.

■ **CAUTION:** Denotes an instruction which, if not followed, may severely damage the engine or other component.

◆ **NOTE:** Indicates supplementary information which may be needed to fully complete or understand an instruction.

|| || | A revision bar outside of page margin indicates a change to text or graphic.

#### 4.2) Safety information

▲ **WARNING:** Only certified technicians (authorized by the local airworthiness authorities) and trained on this product are qualified to work on these engines.

▲ **WARNING:** Never fly the aircraft equipped with this engine at locations, airspeeds, altitudes, of other circumstances from which a successful no-power landing cannot be made, after sudden engine stoppage.

Unless correctly equipped to provide enough electrical power for night VFR (according latest requirement as ASTM), the ROTAX 912 UL/ULS is restricted to DAY VFR only.

## BRP-Powertrain

### INSTALLATION MANUAL

- This engine is not suitable for acrobatics (inverted flight, etc.).
- This engine shall not be used on rotor wing aircraft (helicopters) or any similar aircraft.
- It should be clearly understood that the choice, selection and use *of this* particular engine on any aircraft is at the sole discretion and responsibility of the aircraft manufacturer, assembler and owner/user.
- Due to the varying designs, equipment and types of aircraft, BRP-Powertrain makes no warranty or representation on the suitability of its engine's use on any particular aircraft. Further, BRP-Powertrain makes no warranty or representation of this engine's suitability with any other part, component or system which may be selected by the aircraft manufacturer, assembler or user for aircraft application.
- Unless in a run up area, never run the engine with the propeller turning while on the ground. Do not operate engine if bystanders are close.
- To prevent unauthorized use, never leave the aircraft unattended with the engine running.
- To eliminate possible injury or damage, ensure that any loose equipment or tools are properly secured before starting the engine.
- When in storage protect the engine and fuel system from contamination and exposure.
- Never operate the engine and gearbox without sufficient quantities of lubricating oil.
- Never exceed maximum rated r.p.m. and allow the engine to cool at idle for several minutes before turning off the engine.
- The engine should only be installed and placed into operation by persons familiar with the use of the engine and informed with regard to possible hazards.
- Never run the engine without a propeller as this will inevitably cause engine damage and present a hazard of explosion.
- Propeller and its attachment with a moment of inertia in excess of the specified value must not be used and releases engine manufacturer from any liability.
- Improper engine installation and use of unsuitable piping for fuel,- cooling,- and lubrication system releases engine manufacturer from any liability.
- Unauthorized modifications of engine or aircraft will automatically exclude any liability of the manufacturer for sequential damage.

004632

- In addition to observing the instructions in our Manual, general safety and accident preventative measures, legal regulations and regulations of any aeronautical authority must be observed.
- Where differences exist between this Manual and regulations provided by any authority, the more stringent regulation should be applied.
- This engine may be equipped with an other than the ORIGINAL-ROTAX vacuum pump. The safety warning accompanying the air pump must be given to the owner/operator of the aircraft into which the air pump is installed.

### 4.3) Instruction

Engines require instructions regarding their application, use, operation, maintenance and repair.

- Technical documentation and directions are useful and necessary complementary elements for personal instruction, but can by no means substitute theoretical and practical instructions.
- These instructions should cover explanation of the technical context, advice for operation, maintenance, use and operational safety of the engine.
- All technical directives relevant for safety are especially emphasized. Pass on safety instructions to other users, without fail.
- This engine must only be operated with accessories supplied, recommended and released by BRP-Powertrain. Modifications are only allowed after consent by the engine manufacturer.

■ **CAUTION:** Spare parts must meet with the requirements defined by the engine manufacturer. This is only warranted by use of GENUINE ROTAX spare parts and/or accessories (see Illustrated Parts Catalog).

They are available only at the authorized ROTAX Distribution- and Service Centers.

The use of anything other than genuine ROTAX spare parts and/or accessories will render any warranty relating to this engine null and void (see Warranty Conditions).

▲ **WARNING:** Engine and gear box are delivered in "dry" conditions (without oil). Before putting engine in operation it must be filled with oil. Use only oil as specified (consult Operators Manual and SI-912-016 "Selection of suitable operating fluids" current issue).

## **BRP-Rotax**

### INSTALLATION MANUAL

- ▲ **WARNING:** Exclusively use tools and supplementary materials as listed in the Illustrated Parts Catalog.
- ▲ **WARNING:** This Manual for engine installation is only part of the Technical Documentation and will be supplemented by the respective Operators Manual, Maintenance Manual and Spare Parts List.  
Pay attention to references to other documentation, found in various parts of this Manual.

#### **4.4) Technical documentation**

The information given in the

- Installation Manual
- Operators Manual
- Maintenance Manual (Line Maintenance)
- Maintenance Manual (Heavy Maintenance)
- Overhaul Manual
- Illustrated Parts Catalog (IPC)
- Alert Service Bulletin
- Service Bulletins
- Service Informations
- Service Letter

are based on data and experience that are considered applicable for professionals under normal conditions.

The rapid technical progress and variations of installation might render present laws and regulations inapplicable or inadequate.

The illustrations in this Manual are mere sketches and show a typical arrangement. They may not represent the actual part in all its details but depict parts of the same or similar function. Therefore deduction of dimensions or other details from illustrations is not permitted.

004051

## BRP-Rotax


### INSTALLATION MANUAL

◆ **NOTE:** The illustrations in this Manual are managed in a graphic data base and are identified by a consecutive, non-corresponding number.


This No. (e.g. 00277) does not have any meaning concerning the content!

All necessary documentation is available from the ROTAX Authorized Distributors or their Service Centers.

Installation drawings and a DMU-model for (virtual) installation analysis are available from the ROTAX Authorized Distributors or their Service Centers.



09171



*Fig.1*

09170

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04051



**BRP-Powertrain**  
INSTALLATION MANUAL

## 5) List of the effective pages

00567

chapter	page	date	chapter	page	date	chapter	page	date
0	1	05 01 2007	11	39	05 01 2007	15	91	05 01 2009
	2	05 01 2009		40	05 01 2007		92	05 01 2009
				41	05 01 2007		93	05 01 2009
1	3	05 01 2007		42	05 01 2009		94	05 01 2007
	4	05 01 2007		43	05 01 2007		95	05 01 2007
	5	05 01 2009		44	05 01 2007		96	05 01 2007
	6	05 01 2007		45	05 01 2007		97	05 01 2007
				46	05 01 2007		98	05 01 2007
2	7	05 01 2007	12	47	05 01 2009	16	99	05 01 2009
	8	05 01 2007		48	05 01 2007		100	05 01 2009
3	9	05 01 2009		49	05 01 2007		101	05 01 2007
	10	05 01 2007		50	05 01 2009		102	05 01 2009
4	11	05 01 2009		51	05 01 2009		103	05 01 2009
	12	05 01 2009		52	05 01 2007		104	05 01 2007
	13	05 01 2009		53	05 01 2007		105	05 01 2009
	14	05 01 2007		54	05 01 2007		106	05 01 2009
	15	05 01 2007		55	05 01 2009			
	16	05 01 2007		56	05 01 2007	17	107	05 01 2007
5	17	05 01 2009		57	05 01 2007		108	05 01 2009
	18	05 01 2007		58	05 01 2007		109	05 01 2009
6	19	05 01 2009		59	05 01 2007		110	05 01 2007
	20	05 01 2007		60	05 01 2007		111	05 01 2009
				61	05 01 2009		112	05 01 2007
7	21	05 01 2007		62	05 01 2007		113	05 01 2007
	22	05 01 2009		63	05 01 2007		114	05 01 2007
	23	05 01 2007		64	05 01 2009		115	05 01 2007
	24	05 01 2007		65	05 01 2007		116	05 01 2007
	25	05 01 2007	13	66	05 01 2007		117	05 01 2007
	26	05 01 2007					118	05 01 2009
				67	05 01 2007		119	05 01 2009
8	27	05 01 2007		68	05 01 2007		120	05 01 2007
	28	05 01 2007		69	05 01 2009			
	29	05 01 2007		70	05 01 2007	18	121	05 01 2009
	30	05 01 2007		71	05 01 2007		122	05 01 2007
9	31	05 01 2009		72	05 01 2007			
	32	05 01 2007		73	05 01 2007	19	123	05 01 2007
10	33	05 01 2009		74	05 01 2009		124	05 01 2007
	34	05 01 2007		75	05 01 2007			
	35	05 01 2007		76	05 01 2007	20	125	05 01 2007
	36	05 01 2007		77	05 01 2009		126	05 01 2007
	37	05 01 2007		78	05 01 2007			
	38	05 01 2009		79	05 01 2007	21	127	05 01 2007
			14	80	05 01 2007		128	05 01 2009
				81	05 01 2007		129	05 01 2009
				82	05 01 2007		130	05 01 2009
							131	05 01 2009
				83	05 01 2007		132	05 01 2009
				84	05 01 2007		133	05 01 2007
				85	05 01 2007		134	05 01 2007
				86	05 01 2007			
				87	05 01 2009			
				88	05 01 2007			
				89	05 01 2007			
				90	05 01 2007			

004632

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04051

# INSTALLATION MANUAL

## 6) Table of amendments

### Approval\*

The technical content is approved under the authority  
of DOA Nr. EASA.21J.048.

00568

no.	chapter	page	date of change	remark for approval	date of approval from authorities	date of inclusion	signature
0	0 - 25	all	05 01 2007	DOA*			
1	0	2	05 01 2009	DOA*			
	1	5	05 01 2009	DOA*			
	3	9	05 01 2009	DOA*			
	4	11,12,13	05 01 2009	DOA*			
	5	17	05 01 2009	DOA*			
	6	19	05 01 2009	DOA*			
	7	22	05 01 2009	DOA*			
	9	31	05 01 2009	DOA*			
	10	33, 38	05 01 2009	DOA*			
	11	42	05 01 2009	DOA*			
	12	47, 50, 51, 55,	05 01 2009	DOA*			
		61, 64	05 01 2009	DOA*			
	13	69, 74, 77	05 01 2009	DOA*			
	14	87	05 01 2009	DOA*			
	15	91, 92, 93	05 01 2009	DOA*			
	16	99, 100, 102, 103	05 01 2009	DOA*			
		105, 106	05 01 2009	DOA*			
	17	108, 109, 111,	05 01 2009	DOA*			
		118, 119	05 01 2009	DOA*			
	18	121	05 01 2009	DOA*			
	21	128, 129, 130,	05 01 2009	DOA*			
		131, 132	05 01 2009	DOA*			

d04632

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04051

## 7) Description of design

### 7.1) Designation of type

Basic type

e.g. ROTAX 912 version 2:

**version 2:** with prop flange for fix pitch propeller

**version 3:** with prop flange with drive of hydraulic governor for constant speed propeller

**version 4:** with prop flange for fix pitch propeller, but prepared for retro-fit of hydraulic governor for constant speed prop (not supplied by manufacturer anymore)

Optional extras to the above stated basic type:

	external alternator	vacuum pump	drive for rev-counter/ hour meter	governor
for version 2	yes	yes	yes	no
for version 3	yes	no	yes	yes
for version 4	yes	yes	yes	no

08116

◆ **NOTE:** Conversion of the version 2 / 4 to version 3 may be accomplished by ROTAX Authorized Distributors or their Service Center.

### 7.2) Standard engine design

- 4 stroke, 4 cyl. horizontally opposed, spark ignition engine, single central camshaft hydraulic tappets - push rods - OHV
- liquid cooled cylinder heads
- ram air cooled cylinders
- dry sump, forced lubrication
- dual ignition of breakerless, capacitor discharge design
- 2 constant depression carburetors
- mechanical fuel pumps
- prop drive via integrated gear box with torsional shock absorber and overload clutch (optional on configuration UL2, UL4, ULS2 and ULS4)

## **BRP-Powertrain**

### INSTALLATION MANUAL

- expansion tank (coolant)
- electric starter (standard or with extended power output)
- integrated AC generator with external rectifier regulator
- oil tank
- external start relay
- drive of hydraulic governor (on version 3 only)

#### **Auxiliary equipment (optional)**

■ **CAUTION:** Any equipment not included as part of the standard engine version and thus not a fix component of the engine is not in the volume of supply.

Components especially developed and tested for this engine are readily available at BRP-Powertrain.

**Following auxiliary equipment has been tested on ROTAX engine type 912 for safety and durability to the standards of aviation.**

The furnishing of proof in accordance to the latest FAR or EASA has to be conducted by the aircraft manufacturer.

- airbox
- external alternator
- engine suspension frame
- vacuum pump (feasible on version 2 and version 4 only)
- drive for rev-counter / hour-meter
- oil cooler with connections
- coolant radiator
- coolant overflow bottle

d04633

## BRP-Rotax

### INSTALLATION MANUAL

**Following equipment has not been tested for safety and durability to the standards of aviation.**

▲ **WARNING:** The user assumes all risks possibly arising by utilizing auxiliary equipment.

The furnishing of proof in accordance to the latest FAR or EASA has to be conducted by the aircraft manufacturer.

- exhaust system
- intake filter
- Flydat
- mechanical rev counter
- electric rev counter
- shock mount

# BRP-Rotax

## INSTALLATION MANUAL

### 7.3) Engine components, engine views, definition of main axes

See Fig. 2/3/4/5.

**PTO** power take off side

**MS** magneto side

**A** points of attachment (for engine transport)

⊕ centre of gravity

**P** zero reference point for all dimensions

◆ **NOTE:** Allow  $\pm 1$  mm on all stated dimensions as manufacturing tolerance.

**x,y,z** axes for system of coordinates

**Cyl.1** Cylinder 1

**Cyl.3** Cylinder 3

**Cyl.2** Cylinder 2

**Cyl.4** Cylinder 4

1 engine number

2 propeller flange

3 propeller gear

4 vacuum pump or hydraulic governor for constant speed propeller

5 intake manifold

6 ignition housing

7 ignition cover

8 constant depression carb

9 coolant pump

10 expansion tank

11 oil pump

12 connection for oil return line

13 oil filter

14 electric starter

15 electronic module

16 compensation tube

17 connection for manifold pressure

18 sensor for oil pressure

19 sensor for oil temperature

20 sensor for cylinder head temperature


21 connection for mechanical rev counter

22 mechanical fuel pump

23 oil tank

24 external alternator

25 exhaust socket







# BRP-Rotax

## INSTALLATION MANUAL

**Fig. 3**

00503




00504

**Fig. 4**

**Fig. 5**

09147



004052

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04052

### 8) Technical data

To maintain clarity, only data relevant for engine installation and operation will be stated in the Manual.

◆ **NOTE:** Connecting dimensions, filling capacities, drive and reduction ratios, electric output etc. can be found in the respective chapter of engine installation or other relevant engine documentation. (see section. 4.4)


#### 8.1) Operating limits

1. **Engine speed:** see Operators Manual 912 Series, sec. 10.1.
2. **Manifold pressure:** see Operators Manual 912 Series, sec. 10.1.
3. **Acceleration:** see Operators Manual 912 Series, sec. 10.1.
4. **Critical flight level** see Operators Manual 912 Series, sec. 10.1.
5. **Oil pressure:** see Operators Manual 912 Series, sec. 10.1.
6. **Oil temperature:** see Operators Manual 912 Series, sec. 10.1.
7. **Cyl. head temperature:** see Operators Manual 912 Series, sec. 10.1.
8. **Exhaust gas temperature:** see section 11.1
9. **Range of starting temperature:** see Operators Manual 912 Series, sec. 10.1.
10. **Ambient temperature for electronic module:** see section 19.3
11. **Fuel pressure:** see Operators Manual 912 Series, sec. 10.1.
12. **Banking of plane deviation from the effective vertical:** see Operators Manual 912 Series, sec. 10.1.


The engine design is for a conventional, non-aerobatic, fixed wing tractor or pusher type configuration with the oil return port in the optimum position (see sec. 13.5). With this consideration the engine is properly lubricated in all flight profiles.

The resulting bank angle  $\beta$  (depending on acceleration/deceleration) may never exceed the max. bank angle.

◆ **NOTE:** Pitch or role angle  $\alpha$  is not equal with  $\beta$ , except stabilized condition (without acceleration).



**Fig. 6**  
08325



**Fig. 7**  
07191

$\alpha$  pitch or roll  
 $\beta$  current bank angle  
 F1 gravity  
 F2 acceleration  
 Fr result of F1 and F2

d04052

### 8.2) Installation dimensions

See Fig. 2/3/4.

	Standard engine version		
	pos. (+)	neg. (-)	total
max. dimension in x-axis (mm)	8,5	-581	589,5
max. dimension in y-axis (mm)	288	-288	576,0
max. dimension in z-axis (mm)	118	-276	394,0

09181

◆ NOTE: Dimensions to point of reference (P).

### 8.3) Weight

Weight of engine defined to the following conditions:

- **Engine dry** from serial production with internal alternator, with overload clutch (see section Description of design)

#### ROTAX 912 A, 912 F, 912 UL:

Engine weight..... Version 2 and 4: .....57,1 kg (125 lb)

Version 3: .....59,8 kg (132 lb)

#### ROTAX 912 S, 912 ULS:

Engine weight..... Version 2 and 4: .....58,3 kg (128 lb)

Version 3: .....61,0 kg (134 lb)

#### auxiliary equipment:

Weight of ..... external generator assy. .... 3,0 kg (6.6 lb)  
 overload clutch ..... 1,7 kg (3.7 lb)  
 vacuum pump assy. .... 0,8 kg (1.76 lb)  
 hydraulic governor assy. incl. drive (depending on type)  
 ..... approx. 2,2 (4.8 lb) to 2,7 kg (6 lb)  
 HD-starter ..... additional + 0,43 kg (1 lb)  
 rectifier regulator ..... 0,3 kg (0.66 lb)  
 starter relais ..... 0,145 kg (0.32 lb)  
 radiator ..... 1,0 kg (2.2 lb)  
 air guide hood ..... 0,8 kg (1.8 lb)  
 airbox ..... 1,3 kg (2.8 lb)  
 2 air filter ..... 0,3 kg (0.7 lb)

004052

## BRP-Rotax

### INSTALLATION MANUAL

exhaust system ..... approx. 4,0 kg (8.8 lb)  
oil radiator ..... 0,55 kg (1.2 lb)  
engine mount ..... 2,0 kg (4.4 lb)

#### 8.4) Centre of gravity of engine and standard equipment

See Fig. 2/3/4.

◆ NOTE: Dimensions to point of reference (P).

#### 8.5) Moments of inertia

See Fig. 2/3/4.

	engine from serial production 3	external alternator	hydraulic governor	vacuum pump
centre of gravity in x-axis (mm)	-316	-100	-276	-255
centre of gravity in y-axis (mm)	-5	139	0	0
centre of gravity in z-axis (mm)	-83	6	56	56

09182

	engine version 2 / 4	engine version 3
moment of inertia around axis x1 - x1 (kg cm <sup>2</sup> )	11 100	11 600
moment of inertia around axis y1 - y1 (kg cm <sup>2</sup> )	10 900	11 390
moment of inertia around axis z1 - z1 (kg cm <sup>2</sup> )	17 400	18 200

09183

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04052

## 9) Preparations for engine installation

■ **CAUTION:** The stated directives are measures to pay CAUTION to at engine installation to prevent any accidents and engine damage.

### 9.1) Transport

The engine to be lifted by two hooks or straps around the middle (A) of the intake manifolds.

See chapter engine views, numbering of cylinders and definition of main axes.

### 9.2) State of delivery

The engine could be attached with to steel angles anchored on a timber plate.

■ **CAUTION:** The attachment screws are only for transport and must not be used in the aircraft.

### 9.3) Engine preservation

|| The engine is preserved at BRP-Powertrain thus warranting proper protection against corrosion for at least **12** month after date of delivery from BRP-Powertrain.

|| This warranty is subject to the following conditions:

- ||
- the engine has to be stored in the packing as supplied by BRP-Powertrain.
  - the covers on various openings must not be removed (see section of protective covering)
  - engine has to be stored in a suitable place (at min. - 40 °C (- 40 °F) and max. + 80 °C (+ 176 °F)).

If the engine is stored for a period longer than 12 month perform every 3 months the tasks given in the current valid Maintenance Manual, section "Preservation of a new engine".

**9.4) Protective covering**

All openings are protected against ingress of contamination and dampness. It is recommended not to remove these plugs until installation of the specific feed line.

◆ **NOTE:** If the engine will be sent to the manufacturer or distributor reuse transport equipment and replug openings.

List of protective covering:

- exhaust socket: ..... 1x cone plug
- connection for manifold pressure: ..... 1x cap
- airbox: ..... 2x cap
- fuel pump inlet: ..... 1x cap
- connection for fuel return ..... 1x plug
- connection for fuel pressure ..... 1x plug
- oil supply and oil discharge: ..... 1x each cap
- supply and discharge of coolant: ..... 1x each cone plug
- propshaft on version 3: ..... 1x disk plug
- carburetor (if not equipped with an airbox): .. 2x disk plug

▲ **WARNING:** Protective covering to be utilized for transport and at engine installation only. Before engine operation remove these protections.



## 10) Engine suspension and position

- CAUTION: At installation of engine be aware of engine weight and assure careful handling.

The engine suspension is determined essentially by the aircraft design. Twelve attachment points are provided on the engine (8 on engine and 4 on engine frame).

The engine can be supplied with a well tried and certified suspension frame for attachment on the fire proof bulk head. The airbox is supported on this frame too. The installation into the aircraft is as generally practised by captive rubber mounts which ensure also to balance out vibrations and sound from engine to aircraft frame.


- || ▲ WARNING: If the engine suspension frame supplied by BRP-Powertrain is not used or if modified, certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

It is recommended to use the ROTAX engine suspension frame and the 4 stated attachment points R2, L2, R3 and L3 .

- ▲ WARNING: At least 4 of the given anchorage points must be used in a side symmetrical pattern of the left (L) and right (R) side.

## 10.1) Definition of attachment points

See Fig. 8.



<sup>1)</sup> up to gearbox S/N 28986

<sup>2)</sup> starting from gearbox S/N 28987

▲ **WARNING:** The engine suspension to be designed by the aircraft or fuselage manufacturer such that it will carry safely the maximum occurring operational loads without exceeding the max. allowable-forces and moments on the engine attachment points.

d04053

# BRP-Rotax

## INSTALLATION MANUAL

		attachment point								attachment point			
										L5	R5	L6	R6
09185		L1	R1	L2	R2	L3	R3	L4	R4				
max. allowable forces (limit load) in (N) in x, y and z axis		5000								max. allowable forces (limit load) in (N) in x axis			
										in y axis			
										in z axis			
max. allowable bending moment (limit load) in (Nm) in x, y and z axis		77								max. allowable bending moment (limit load) in (Nm) in x, y and z axis			
		1900								5 000			
										2 000			
										3 000			
										100			

▲ **WARNING:** Tighten all engine suspension screws as specified by the aircraft manufacturer.

## 10.2) Permissible fitting positions

See Fig. 9/10/11.

To simplify the matter, reference is made only to the 4 engine attachment points R1, L1, R2 and L2.

◆ **NOTE:** All dimensions to point of reference (P) and the system of coordinates remain unchanged.

**The following details of engine position are with reference to aircraft on ground, ready for take off.**

- engine suitable for propeller in tractor or pusher arrangement,
- propeller shaft above cylinders. See Fig. 2.

▲ **WARNING:** For upside down installation of the engine, the lubrication system, fuel system and the cooling system are unsuitable!

### Longitudinal axis:

- The centre of the attachment points L1 and L2 must be on axis x2 parallel to the x axis.

### **Allowable pitch deviation of parallelism of axes:**

- max. 6° counter-clockwise, **on ground**
- max. 10° counter-clockwise, **in operation**
- max. 30° clockwise (see Fig. 9)


▲ **WARNING:** On installations with fuel tank located above carburetor level combined with badly closing carb float valve, fuel could pass into cylinders at more than 6° decline of propeller shaft axis after longer periods of downtime. See FAR, § 33.17.

d04053

# BRP-Rotax

## INSTALLATION MANUAL

To prevent a possible hydraulic shock at engine start, ensure proper closing of float valves. If in doubt, park the aircraft with inclining propeller shaft axis.




**Fig. 9**

09136

### Propeller axis:

- The centres of attachment points L1 and R1 must be on an axis y2 parallel to y-axis.



**Fig. 10**

02454


**Tolerated roll deviation of parallelism:** .....  $\pm 5^\circ$ . (see Fig. 10)

d04053

**BRP-Rotax**  
INSTALLATION MANUAL

**Vertical axis:**

- y-axis must be square to the longitudinal axis of the aircraft.



**Fig. 11**


02455

**Tolerated roll deviation of Yaw tolerance:  $\pm 10^\circ$  (see Fig. 11)**

### 10.3) General directives for engine suspension

Rubber mounts to be used between engine and aircraft frame to neutralize vibrations.

Damping elements as generally used in the aircraft industry (e.g. LORD) are suitable. See Fig. 12.



#### ◆ NOTE:

The Fig. shows rubber mount Lord J 3608-1 resp. J 3608-2.

#### ▲ WARNING:

All elements to balance out vibrations have to be of captive design.

07600

Fig. 12

#### ◆ NOTE:

With suspension on the 4 top lugs L3, R3, L4 and R4 only, the tilting moment due to the pull of the propeller will be avoided while, if attached on the bottom lugs only, the moment of tilting has to be taken care of accordingly.

#### ◆ NOTE:

A certified engine suspension frame has been developed by BRP-Powertrain, especially for the magneto side engine attachment to the fireproof bulk head.

#### ▲ WARNING:

If the engine suspension frame supplied by BRP-Powertrain is not used the engine installation must be ground run tested to the specified loads and for vibration behaviour. Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

#### ▲ WARNING:

The rubber mounts to neutralize vibrations and all the engine suspension components not in the supply volume must be ground run tested to the specified loads and for vibration behaviour. Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

#### ■ CAUTION:

The engine suspension has to be designed to prevent any excessive engine movement and to minimize noise emission and vibration on air frame side.

See also SL-912-010 "Identifying abnormal vibrations on aircrafts", latest issue.

d04634

## 11) Exhaust system

See Fig. 2, 3 and 4.

The shape and execution of the exhaust system is determined essentially by the free space available in the aircraft.

For attaching, the exhaust system two studs M8x23 are provided on each cylinder.

### Location of the studs:

location	coordinates [mm]		
	x axis	y axis	z axis
cylinder 1	-160	-196	-82
	-160	-212	-113
cylinder 2	-192	196	-82
	-192	212	-113
cylinder 3	-408	-196	-82
	-408	-212	-113
cylinder 4	-438	196	-82
	-438	212	-113

09189

◆ NOTE: All dimension to point of reference (P).

	points of attachment
max. allowable forces (limit load) in (N) in x,y and z axis	1 000
max. allowable bending (limit load) in (N) in x,y and z axis	40

02023

▲ WARNING: The exhaust system has to be designed by the aircraft or fuselage manufacturer such, that the limit loads on the points of attachment will not be exceeded. Additional support of exhaust system may be necessary.

**11.1) Requirements on the exhaust system**

See Fig. 13.


- mean bending radius of exhaust bend : min. 40 mm (1.6 in.)
- exhaust bend, inside dia.: min. 28 mm (1.1 in.)
- muffler volume: approx. 5 l (1.32 US gal)
- back pressure at takeoff performance: max. 0,2 bar (2.9 psi.) (readings taken approx. 100 mm (3.93 in.) from exhaust flange connections).
- The 4 exhaust sockets included in the supply scope have to be used without exception. See fig. 13.

Material of the exhaust sockets: X 6 CrNiTi 1810 (DIN 1.4541)

Tightening torque of the lock nut M8

for the exhaust flange: 12-20 Nm (106 -177 in.lb.) Pay also attention on SI-05-1997.

- **CAUTION:** Fit heat shields near carburetors or as required.  
Because of the high temperatures occurring, provide suitable protection against unintentional contact.
- **CAUTION:** Secure exhaust system by suitable means according to installation.





**11.2) operating limits**

See Fig. 14.


- exhaust gas temperature (EGT):  
(both ignition circuits active)

nominal approx. 800 °C (1470 °F)
max. 850 °C (1560 °F)
max. 880 °C (1616 °F) at take off
(readings of EGT taken approx. 100 mm (3.93 in.) from exhaust flange connections).

The exhaust gas temperatures (EGT) have to be measured at the initial engine installation in an aircraft and must be verified in the course of test flights.

▲ **WARNING:** The exhaust system has to be designed and built such, that the operating temperatures are maintained and the max. exhaust gas temperatures will never be exceeded.

■ **CAUTION:** The listed engine performance is given at ISA ((15 °C) (59 °F)) conditions only on engine that is equipped with an unmodified ROTAX tuned exhaust muffler system and air intake box.



07131

**Fig. 14**

### 11.3) General directives for exhaust-system

See Fig. 15.

A exhaust system, especially for universal application has been developed by BRP-Powertrain. Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

The following recommendations should help the aircraft manufacturer to plan a suitable exhaust system.

◆ **NOTE:** These recommendations derive from years of experience and the results achieved are generally very good.

- A common transversal muffler serving all 4 cylinders and positioned under the engine is favourable.

◆ **NOTE:** Equal length of pipes from the cylinder to muffler is recommended for better tuning.

Distribution of the exhaust gases into 2 separate systems is not recommended. Single mufflers on either side cause power loss and increased noise emission.

- The 4 ball joints must be used to avoid damage due to vibration.

Be aware that locked up stresses cause cracks!

Attachment of exhaust bends by springs!

Springs to be secured with safety wire to prevent FOD!

All ball joints have to be greased regularly with heat resistant lubricant (e.g. LOCTITE ANTISEIZE) to avoid gripping and seizing of the joints.

■ **CAUTION:** Vibrations due to improper installation and maintenance is the most common reason for damage of the exhaust system.


## BRP-Rotax

### INSTALLATION MANUAL

The sketch illustrates a possibility how to interconnect the exhaust springs to prevent the vibration of these springs and thus premature wear.

It is also recommended to fill the springs with high heat silicone for additional damping of vibrations.

■ **CAUTION:** Appropriate to the installation a vibration damping support for the exhaust system has to be provided on the airframe manufacturers side.




#### 11.4) Data for optional components of exhaust system

- weight: see section 8.
- exhaust elbow assy. (doughnut)

See Fig. 16.

Material/thickness of the exhaust components:

X 15CrNiSi20-12 (1.4828) (AISI 309)  $a = 1.5 \text{ mm (0.059 in.)}$



d04053

## BRP-Rotax


### INSTALLATION MANUAL

- muffler assy.

See Fig. 17.

Material/thickness of the exhaust components:

X 6CrNiTi 189 (1.4541) (stainless) a= 1 mm (0.039 in.)




- exhaust elbow (tailpipe)

See Fig. 18.

Material/thickness of the exhaust components:

X 5CrNi 189 (1.4301) (stainless) a= 1 mm (0.039 in.)



09153

**Fig. 18**

d04053

## BRP-Rotax


### INSTALLATION MANUAL

- ball joint, male

See Fig. 19.

Material/thickness of the exhaust components:

X 15CrNiSi 20,12 (DIN 1.4828) (stainless)  $a = 1 \text{ mm}$  (0.039 in.)



09166


**Fig. 19**

- exhaust tube

See Fig. 20.

Material/thickness of the exhaust components:

X 15CrNiSi 20,12 (DIN 1.4828) (stainless)  $a = 1 \text{ mm}$  (0.039 in.)



09167

**Fig. 20**

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04053

## 12) Cooling system

### 12.1) Description of the system


See Fig. 21.

The cooling system of the ROTAX 912 is designed for liquid cooling of the cylinder heads and ram-air cooling of the cylinders.

The cooling system of the cylinder heads is a **closed** circuit with an expansion tank and overflow bottle.

The coolant flow is forced by a water pump, driven from the camshaft, from the radiator to the cylinder heads. From the top of the cylinder heads the coolant passes on to the expansion tank (1). Since the standard location of the radiator (2) is below engine level, the expansion tank located on top of the engine allows for coolant expansion.

The expansion tank is closed by a pressure cap (3) (with pressure relief valve and return valve). At temperature rise and expansion of the coolant the pressure relief valve opens and the coolant will flow via a hose at atmospheric pressure to the transparent overflow bottle (4). When cooling down, the coolant will be sucked back into the cooling circuit.



The shape, size and location of one or more radiators depend mainly on the space available.

On good installation in the airplane the radiator by BRP-Powertrain (optional) has enough cooling capacity to keep within the normal specified operating limits. Also the flow of coolant liquid through the radiator is not restricted and the tube size is sufficient.

## **12.2) Operating Limits**

### **Using conventional coolant:**

Coolant temperature: (coolant exit temperature)

max.....120 °C (248 °F)

Cylinder head temperature:

ROTAX 912 UL/A/F: max.....150 °C (300 °F)

ROTAX 912 ULS/S: max.....135 °C (275 °F)

Permanent monitoring of coolant temperature and cylinder head temperature is necessary.

### **Using waterless coolant:**

Cylinder head temperature:

ROTAX 912 UL/A/F: max.....150 °C (300 °F)

ROTAX 912 ULS/S: max.....135 °C (275 °F)

Permanent monitoring of cylinder head temperature is necessary.

Additional monitoring of the actual coolant temperature is possible but not necessary for waterless coolant.

▲ **WARNING:** The cooling system has to be designed so that operating temperatures will not be more than the maximum values.

Monitoring the cylinder head temperature is important to control the engine cooling and prevents detonation within the operating limits. It is also necessary to design the cooling circuit so that under no conditions the coolant does get near its boiling point, because a subsequent loss of coolant can quickly cause the engine to overheat.

The boiling point of the coolant is influenced mainly by:

- the type of coolant
- the proportion of the mixture (percentage water rate)
- the system pressure (opening pressure of radiator cap)

### **Correlation between coolant temperature and cylinder head temperature**

There is in principle a regular relationship between coolant temperature and cylinder head temperature. The coolant transfers some of the combustion heat to the radiator. Thus, the coolant temperature is usually lower than the cylinder head temperature. But the temperature difference between coolant and cylinder head is not constant and can vary with different engine installation (cowling or free installation, tractor or pusher, flight speed, etc.).

d04054



- ◆ **NOTE:** The basic requirement for safe operation is that boiling of conventional coolant must be prevented. The boiling point of conventional coolant is 120 °C (248 °F) with a 50/50 mixture proportion and a system pressure of 1.2 bar (18 psi).

### **12.3) Coolant types**

In principle, 2 different types of coolant are permitted.

#### **Type 1:**

- Conventional coolant based on ethylene glycol

Conventional coolant is recommended as it is commonly available and has a greater thermal heat transfer capability. Its limitation is its lower boiling point.

Conventional coolant should be used with a mixture of 50 % concentrate and 50 % water.

- ◆ **NOTE:** Some conventional coolant is available pre-mixed by the manufacturer. In this case do not mix with water, follow the manufacturers instructions on the container.

Conventional coolant with a rate of 50% water cannot boil at a temperature below 120 °C (248 °F) at a pressure of 1.2 bar (18 psi). Thus, the coolant temperature limit is at max. 120 °C (248 °F).

Permanent monitoring of coolant temperature and cylinder head temperature is necessary.

#### **Type 2:**

- Waterless coolant based on propylene glycol

Waterless coolant is recommended if the design of the aircraft can not maintain the coolant temperature limit. Waterless coolant has a very high boiling point that prevents coolant loss due to „boiling over“ (vapor loss), but not to prevent detonation, which can occur with cylinder head temperatures higher than 150 °C (300 °F) (for ROTAX 912 UL/A/F) and 135 °C (275 °F) (for ROTAX 912 ULS/S). It does not require pressure to maintain its boiling point. Due to a lower thermal conductivity the engine temperature will typically run about 5-10 °C (41-50 °F) higher with waterless coolant.

Permanent monitoring of cylinder head temperature is necessary.

Additional monitoring of the actual coolant temperature is possible but not necessary for waterless coolant.

## BRP-Powertrain

### INSTALLATION MANUAL


- ◆ **NOTE:** When using EVANS NPGR, NPG+ or added pure ethylene glycol as a coolant, note that these fluids have a flammability rating 1 (classification LOW at a scale from 0 to 4). The mentioned coolants are complying according to their material safety data sheet with a flammability classification, which has only low danger and a low risk of flammability. To date, no cases in engine operation or flight operation, laboratory conditions or from the field were reported, which show unsafe conditions of ROTAX aircraft engines in combination with the relevant coolants.

#### Marking of the coolant to be used

- **CAUTION:** The coolant to be used and its concentration (percentage water rate) must be communicated to the owner in the correct form.
- Waterless coolant must not mix with water, as otherwise it will lose the advantages of a high boiling point.


Example: EVANS NPG+. See Fig. 22.

- 1 Warning sticker
- 2 Radiator cap
- 3 Opening pressure information of radiator cap.



#### 12.4) Check cooling system - Efficiency of the cooling system

For a measurement of the cooling system the maximum values for coolant exit temperature and cylinder head temperature must be found. According to the current specifications.




d04635

**12.4.1) Measurement of cylinder head temperature and coolant exit temperature**

There are two temperature sensors (1) (see Fig. 23) on the cylinder 2 and 3 for measuring the cylinder head temperature. During flight test the place with the highest cylinder head temperature must be found, this can vary with different engine installation (cowling or free installation, tractor or pusher, fight speed etc.).

The measuring of the coolant exit temperature is performed using a separate sensor, which has to be installed in the line between expansion tank (1) and radiator inlet (2).



The sensor may be installed in a "TEE" inline with the fluid hose or the expansion tank may be modified to attach the sensor (not supplied by BRP-Powertrain).

- ▲ **WARNING:** Do not restrict the coolant flow with the sensor device.
- **CAUTION:** It is possible to receive a misleading reading when measuring fluid temperatures. If fluid volume is lost and the probe is not fully submerged in the fluid the display could show a lower temperature than actual (measuring air temperature instead of fluid temperature).

## 12.5) Determination of operating limits, Coolant and necessary modification on radiator installation

Depending on the achieved maximum values of the cylinder head temperature and the coolant temperature following action are necessary. 08358

maximum values for		coolant used for tests	
Coolant temperature	Cylinder head temperature	Conventional coolant	Waterless coolant
less than 120 °C (248 °F)	less than 135 °C <sup>1)</sup> (275 °F) 150 °C <sup>2)</sup> (300 °F)	Additional instruments for displaying coolant temperature is necessary <b>b)</b>	Modifications to the instruments or limit not necessary <b>a)</b>
more than 120 °C (248 °F)	less than 135 °C <sup>1)</sup> (275 °F) 150 °C <sup>2)</sup> (300 °F)	Cooling capacity too low. Check of the installation necessary <b>c)</b>	
less than 120 °C (248 °F)	more than 135 °C <sup>1)</sup> (275 °F) 150 °C <sup>2)</sup> (300 °F)		
more than 120 °C (248 °F)	more than 135 °C <sup>1)</sup> (275 °F) 150 °C <sup>2)</sup> (300 °F)		Cooling capacity too low. Check of the installation necessary <b>c)</b>

<sup>1)</sup> engine type 912 ULS/S

<sup>2)</sup> engine type 912 UL/A/F

- a)** Maximum cylinder head temperature is below operating limit. Operating with waterless coolant, is permissible without modification to the installation.
- b)** Maximum cylinder head temperature and coolant exit temperature is below operating limit.

For operating with conventional coolant it is necessary to monitoring constantly cylinder head temperature and coolant exit temperature.

- ◆ **NOTE:** For detection of possible indication error an additional monitoring of the cylinder head temperature is necessary which shows an exceeding in case of coolant loss.

The aircraft manufacturer has the option of converting the coolant temperature and the cylinder head temperature to an aircraft specific cylinder head temperature. This is possible by calculating the difference between the head material and the coolant temperature.

This is done by following the flight test procedure on page 53.

d04054

## BRP-Rotax

### INSTALLATION MANUAL

Once the calculation is made and the indicating instrument re-labelled it is acceptable to use the cylinder head temperature as the primary cockpit display instead of installing a sensor in the coolant flow.

The measurement is based on the maximum coolant temperature and cylinder head temperature according to the current requirement.

■ **CAUTION:** In no case a cylinder head temperature higher than the limit of 150 °C (300 °F) (for ROTAX 912 UL/A/F) and 135 °C (275 °F) (for ROTAX 912 ULS/S) can be defined because detonation could not be sufficiently prevented.

Refer to the flight test example that follows.

c) Cooling capacity of the installation too low.

#### **Flight test example:**

Calculated values (maximum values found for coolant temperature and cylinder head temperature. Refer to the current specification of the FAA and/or EASA):

Coolant temperature.....102 °C (216 °F)

Cylinder head temperature.....110 °C (230 °F)

The cylinder head temperature is 8 °C (46 °F) higher than the coolant temperature.

Thus:

Coolant temperature limit.....120 °C (248 °F)

Difference cylinder head and coolant temperature.....+ 8 °C ( 46 °F)  
= 128 °C (262 °F)

The highest cylinder head temperature permitted is 128 °C (262 °F), so that the max. coolant temperature is kept.

With this special application, safe operation of the engine that prevents boiling of the coolant is possible up to a cylinder head temperature of 128 °C (262 °F).

■ **CAUTION:** This cylinder head temperature with the limit found for this type must be displayed constantly in the cockpit.

The indicating instrument and the manuals must be changed to cylinder head temperature max. 128 °C (262 °F).

■ **CAUTION:** The design of the radiator installation must be changed (example: cowl modifications), if the operating temperature exceeds the specified limits.

d04054

**12.6) Requirements on the cooling system**

■ **CAUTION:** All components of the cooling system have to be secured suitably.

▲ **WARNING:** The size and layout of the cooling system must be designed to keep the operating temperatures within the specified limits.



To minimize flow resistance employ radiator with low flow resistance and parallel flow as realized on the original ROTAX radiator and use short hoses and pipelines.

**Coolant hoses:**

- temperature durability: min. 125 °C (257 °F)
- pressure durability: min. 5 bar (73 psi.)
- nom. inside dia : 25 mm (1")
- bending radius: min. 175 mm (7")
- material: Suitable for 100 % Glycol and antifreeze agents.  
Pay CAUTION to ozone stability!

■ **CAUTION:** Hoses exposed to direct heat radiation of exhaust system, have to be protected with heat-resistant protection tubes.

◆ **NOTE:** If installation require longer distances use aluminium pipes (25 mm (1") inside dia.) instead of hoses. These should have a bulge (1) in order to prevent coolant hoses becoming loose.



09158

**Fig. 25**

### Expansion tank to overflow bottle hose:

- Hose connecting expansion tank to overflow bottle must be rated for vacuum/suction for min. 125 °C (257 °F). E.g. it must be strong enough to withstand high heat and suction during the cooling down period.
- ▲ **WARNING:** A soft walled hose is not suitable as it can collapse and cause coolant system failure.

### 12.7) Size and position of connections

See Fig. 26/27/28.

- expansion tank (1) with radiator cap (2)

to radiator (3):	outside dia. 25 mm (1")
slip-on length	max. 22 mm (7/8")
to overflow bottle (4):	outside dia. 8 mm (3/8")
slip-on length	max. 15 mm (9/16")


- **CAUTION:** The hoses have to be fixed with appropriate clamps to prevent loss. E.g. with spring type clamps as used already for the water tubes between water pump and cylinder. Good field experience has been made with this type of clamps.

- ◆ **NOTE:** See therefore also SI-912-020 "Running modifications", latest issue.

The aircraft manufacturer has to carry out the check of coolant level in the expansion tank and note it in the daily inspection section of his flight manual according latest issue of Operators Manual ROTAX 912.

It is recommended to make adequate precautions for accomplishment of these inspections, e.g. a flap or panel on the cowling or a warning instrument in the cockpit for low coolant level.

**BRP-Rotax**  
INSTALLATION MANUAL



07136  
**Fig. 26**



d04054



## BRP-Rotax

### INSTALLATION MANUAL

- water inlet bend (5): outside dia. 27 mm (1 1/16")  
slip-on length max. 19 mm (3/4")



◆ **NOTE:**

Choose between six possible fitting positions of water inlet bend (5) appropriate to specific installation (see Fig. 27). The inlet bend is attached to the water pump by two Allen screws M6x20 and lock washers. Tighten screws to 10 Nm (90 in.lb.).

■ **CAUTION:**

Utilize total slip-on length for hose connection. Secure hoses with suitable spring type clamp or screw clamp.


## 12.8) Feasible location of radiator

See Fig. 29.

The expansion tank (1) must always be positioned at the highest point of the cooling system.

■ **CAUTION:** If necessary, the radiator outlet opening (8) may be max. **1,5 m** (5 ft) above or below water inlet bend (5) on water pump (see Fig. 29).

◆ **NOTE:** On the standard engine version the expansion tank (1) is fitted on top of the engine (see Fig. 29).



For proper operation of the cooling system the expansion tank (1) with pressure cap (2) has to remain for all possible engine positions on the highest point of the cooling circuit.

▲ **WARNING:** The radiator has to be planned and installed such that the specified operating temperatures are maintained and the max. values are not exceeded.

This state has to be warranted for "**hot day conditions**" too!

If need be, take appropriate measures like changing size of cooler, partial covering of cooler etc.

Additionally the system needs an overflow bottle (7) where surplus coolant is collected and returned back into the circuit at the cooling down period.

d04054

## BRP-Rotax

### INSTALLATION MANUAL

- ◆ **NOTE:** For proper operation keep hose to overflow bottle as short and small as possible (see section 12.6 Expansion tank to overflow bottle hose ).
- **CAUTION:** To warrant the proper operation of the cooling system the delivery head between overflow bottle and expansion tank must not exceed 250 mm (10").

#### Requirements on the overflow bottle (7)

- transparent material
- unaffected by temperatures from - 40 °C (- 40 °F) to +125 °C (257 °F)
- resistant against 100% Glycol and any other anti freeze agent
- volume approx. 0,5 l (.13 US gal)
- possible to vent (6), diameter 2.5 mm (0.1 in.)

- ◆ **NOTE:** The overflow bottle ought to be furnished with a label indicating function and content.

- ▲ **WARNING:** Ensure that the overflow bottle will never be empty, otherwise air will be sucked into cooling circuit causing cooling system failure.


- **CAUTION:** The overflow bottle and their supply and discharge will never be install direct of the exhaust system, coolant can be sometimes to inflame.

- ◆ **NOTE:** To vent coolant steam from the expansion bottle in case of overheating, the plastic cap can be retrofitted with a hose nipple and hose.

The vent line (5) has to be routed in a way that no coolant can get in contact with the hot exhaust system.

The venting line must be routed in a continuous decline or furnished with a drain bore at it's lowest point to drain possible condensation.

The vent line has to be protected from any kind of ice formation from condensation. Protection by insulation, or routing in a hose with hot air flow or by furnishing the vent line with a bypass opening (slot) (6) before passing through cowling (7). See Fig. 30.



09132

Fig. 30

d04054




## BRP-Rotax

### INSTALLATION MANUAL

- Unscrew cap (2) from the overflow bottle.
- Bore the existing vent hole from dia. 1mm (0.04 in.) to dia. 6mm (0.236 in.)
- Apply LOCTITE® 603 to the threads of the hose nipple (3).
- Insert nipple (3) into the vent hole.
- Install nut (1) onto the hose nipple (3). Tightening torque 5 Nm (44 in lb).
- Screw the cap onto the overflow bottle.

Steps to attach the hose:

- Attach the hose with a gear-type hose clamp (4).
- Make sure the hose (5) has no kinks. Route it overboard and secure.




d04054

**12.9) General directives for the cooling system**

See Fig. 29.

BRP-Powertrain offers essential parts of the cooling system for this engine such as radiator, etc..

▲ **WARNING:** Certification to the latest requirements to FAR or EASA has to be conducted by the aircraft manufacturer.



In an installation as depicted with the radiator (9) in a higher position than the standard supplied expansion tank, a water accumulator (10) has to be fitted instead of the expansion tank. Additionally a suitable expansion tank (1) has to be installed at the highest point of the cooling circuit.

■ **CAUTION:** The size and type of radiator should be adequate to transfer thermal energy of  
approx. 25 kW (24 BTU/s) (for ROTAX 912 A/F/UL) or  
approx. 28 kW (26,5 BTU/s) (for ROTAX 912 S/ULS)  
at take-off power.

◆ **NOTE:** Assessment data by experience. For troublefree operation at good airflow a radiator of at least 500 cm<sup>2</sup> (78 in<sup>2</sup>) area has to be used.

The flow rate of coolant in the cooling system is approx. 60 l/min (16 US gal/min) at 5800 rpm. As reference value for the necessary cooling airflow approx. 0,75 m<sup>3</sup>/s at full load can be assumed.

The flow resistance of the coolant in the optional ROTAX-radiator is properly designed for the cooling system.  
Check flow rate and cooling capacity if other radiators are used.

## **BRP-Rotax**

### INSTALLATION MANUAL

No provision has been made for attachment of the radiator(s) on the engine.

■ **CAUTION:** Install the radiator without distortion or stress and free of vibrations (rubber mounts are recommended).

At installation of a non-original ROTAX radiator take care of sufficient cooling capacity. See section 12.7

d04054

**12.10)Coolant capacity**

4 cylinder heads: ..... 560 cm<sup>3</sup> (34.1 in<sup>3</sup>)  
water pump: ..... 100 cm<sup>3</sup> (6.10 in<sup>3</sup>)  
expansion tank: ..... 250 cm<sup>3</sup> (15.2 in<sup>3</sup>)  
2 m coolant hose  
(18 mm (.71 in) inside dia.) : ..... 500 cm<sup>3</sup> (30.5 in<sup>3</sup>)  
  
total coolant quantity in engine: ..... approx. 1,5 l (0.4 gal (US))


**12.11)Cooling air ducting**

Contrary to the cylinder heads, the cylinders are ram air cooled. Plan cooling air ducting according to installation requirement.

▲ **WARNING:** The cooling air ducting has to be designed and built such, that the operating temperatures are kept within the specified limits and maximum values are not exceeded.

This must also be warranted at "**hot day conditions**"!

Max. permissible cylinder wall temperature on cylinder 2....200 °C (392 °F)  
(see Fig. 36).



### 12.11.1) General directives for ducting of the cooling air

See Fig. 2/3/4.

For front installation in a closed fuselage, ducting of cooling air to the cylinders is recommended. In this case a costly horizontal partitioning (baffles) can be avoided.

- ◆ NOTE: The engine remains in this case completely on the warm side of the engine compartment and is very well accessible. In special cases a separate cold air supply to the air intake filters has to be provided.

BRP-Powertrain has developed especially for this application a non-certified cooling air ducting.

- ▲ WARNING: Certification to the latest requirements to FAR or EASA has to be conducted by the aircraft manufacturer.

**The following recommendations should assist the aircraft manufacturer at the planning of a suitable cooling air ducting.**

- The cooling air ducting to be adequate to transfer thermal energy of approx. 6 kW (5,7 BTU/s) at take-off power.
- required cross section of air duct: at least 100 cm<sup>2</sup> (16 in<sup>2</sup>)
- material:  
glass fibre reinforced plastic or heat resistant non-inflammable material.
- attachment:  
formlocking on engine case and cylinders
- ◆ NOTE: In case formlocking attachment won't be adequate, additional attachment is possible on two tapped lugs M8 on top side of engine.



# BRP-Rotax

## INSTALLATION MANUAL


- **CAUTION:** The stated limit loads are valid only at utilization of min specified thread length, and must never be exceeded.  
Depth of thread 18 mm (.71 in).

04864				04876		attachment points
attachment points	Axes			max. allowable forces (limit load) in (N) in x, y and z axis	2 000	
	x axis mm (in.)	y axis mm (in.)	z axis mm (in.)	max. allowable bending moment (limit load) in (Nm) in x, y and z axis	50	
	-300 (-11.81 in)	-30 (-1.18 in)	-14 (-0.55 in)	min. length of thread engagement (mm)	15 (0.59 in)	

### 12.12)Data for optional components of cooling system

- overflow bottle

See Fig. 37.



09148

Fig. 37


## BRP-Rotax

### INSTALLATION MANUAL

- radiator

See Fig. 38.


- weight: see section 8.



- cooling air baffle

See Fig. 39.

- weight: see section 8.



#### ◆ NOTE:

The gap between cowling and radiator should be covered by appropriate sealing lips for better efficiency of cooling.

d04054

## 13) Lubrication system

### 13.1) Description of the system

See Fig. 40.

The ROTAX 912 engine is provided with a dry sump forced lubrication system with a oil pump with integrated pressure regulator.

◆ **NOTE:** The oil pump is driven by the camshaft.

The oil pump sucks the motor oil from the oil tank (1) via the oil cooler (2) and forces it through the oil filter to the points of lubrication (lubricates also the propeller governor).


The surplus oil emerging from the points of lubrication accumulates on the bottom of crankcase and is forced back to the oil tank by the piston blow-by gases.

◆ **NOTE:** The oil circuit is vented via nipple (3) in the oil tank.

For the completion of the lubrication system only the following connections need to be established:

#### Oil circuit

oil tank (outlet)	to	oil cooler
oil cooler	to	oil pump (inlet)
oil return	to	oil tank (inlet)
oil tank	-	venting line



**Fig. 40**

09160

## BRP-Rotax

### INSTALLATION MANUAL

- ◆ NOTE: In the serial version of the engine an oil tank is included, but no provision is made for attachment of an oil cooler.
- ▲ WARNING: Certification of oil cooler and connections to the latest requirements such as FAR and EASA has to be conducted by the aircraft manufacturer.

#### 13.2) Limits of operation

- ▲ WARNING: The lubrication system has to be designed such that operating temperatures will not exceed the specified limits.

**Oil pressure:** For oil pressure sensor see Fig. 88/89.

see OM 912 Series, section 10.1

**Oil temperature:** Oil temperature sensor, see Fig. 86/87.

see OM 912 Series, section 10.1

- ▲ WARNING: At operation below nominal oil temperature formation of condensate in the lubrication system might influence oil quality.
- ◆ NOTE: For operation at low temperatures the installation of an oil thermostat, parallel to the oil cooler, is strongly recommended.  
Advantages: safe oil pressure after cold start, prevention of fuel and water accumulation in the oil.  
See therefore SL-912-011 "Use of an oil thermostat", latest issue.

d04055

### 13.3) Checking of the lubrication system

To control the proper function of the lubrication system the following readings have to be taken on the running engine as part of the test/qualification procedure.


◆ **NOTE:** The required pressure gauges and connection parts are not included in the BRP-Powertrain engine delivery.

#### 13.3.1) Measuring of the vacuum

Measuring of vacuum in the oil suction line (1) (line from oil tank to oil pump via oil cooler) at a max. distance of 100 mm (4 in) from pump inlet (2).

At take-off performance the indicated vacuum (3) must not be more than 0,3 bar (4.35 psi) otherwise the oil hose (1) could collapse and thus blocking the oil supply to the engine (Fig. 41).

▲ **WARNING:** The vacuum (3) must be verified over the total range of engine operation. Specially on cold oil temperature the flow resistance increases, so that not enough oil can flow on suction side.



**Fig. 41**

09161

max. 0.3 bar (4.35 psi) below atmospheric pressure

**13.3.2) Measuring of the pressure in the crankcase**

Measure of the mean crankcase pressure at full load (blow-by gas pressure) responsible for proper oil return from crankcase to oil tank.

A pressure indicator (4) (pressure gauge with incorporated viscous damper) may be fitted instead of the magnetic plug (5) or the crankshaft locking screw (6) (see Fig. 42).


- ◆ **NOTE:** The connecting thread is M12x1.5 (metric) for the magnetic plug and M8 for the crankshaft locking screw (use always new gasket).

The pressure in the crankcase at full load must not exceed the prevailing ambient pressure by more than 0,45 bar (6.53 psi) at 90 °C (194 °F) oil temperature.

If both pressure readings are within the specified limits, under all operating conditions, the lubrication circuit should be working sufficiently.

- ▲ **WARNING:** If the readings exceed the pressure limits then the flow resistance of the oil from oil sump to oil tank (contamination, restrictions of cross-section etc.) is too high. This condition is unsafe and must be rectified without delay.

max. 0,45 bar (6.53 psi) above atmospheric pressure



**Fig. 42**

08324

d04055

**13.4) Requirements on the oil- and venting lines****Oil lines****Oil circuit, engine**

- Temperature durability: mind. 140 °C (285 °F)
- Pressure durability: mind. 10 bar (145 psi.)
- Bending radius: mind. 70 mm (2.75 in) \*  
\* unless otherwise stated by the hose manufacturer
- Minimum inside dia. of oil lines in reference to total length
  - length up to... 1 m (3 '3") min. 11 mm ø (.43")
  - length up to... 2 m (6' 6") min. 12 mm ø (.47")
  - length up to... 3 m (10') min. 13 mm ø (.51")
- Length of a single oil line: max. 3 m (118.11 in.)


**Vent line of oil tank**

- Route the line without kinks and avoid sharp bends.

◆ **NOTE:** Water is a by-product of combustion. Most of this water will dissipate from the combustion chamber with the exhaust gases.

A small amount will reach the crankcase and has to be disposed through the vent line of oil tank via oil return line.

- The venting line must be routed in a continuous decline or furnished with a drain bore at it's lowest point to drain possible condensate.
- The vent line has to be protected from any kind of ice formation in the condensate. Protection by insulation, or routing in a hose with hot air flow or by furnishing vent line with a bypass opening (1) before passing through cowling (2). See Fig. 43.

**Fig. 43**

09132

**13.5) Connecting dimensions and location of connections**

- **CAUTION:** Utilize the full slip-on length for hose connections. Secure hoses with suitable screw clamp or by crimp connection.
- ◆ **NOTE:** The oil pipeline connections are optional as UNF-thread (AN-8). See SI-912-003.

**13.5.1) Oil circuit (engine)**

See Fig. 44, 45, 46 and 47.


Depending on engine certification, the oil pump inlet connectors can vary:

- 912 A/F/S .. thread M18 - optional UNF-thread (AN-8)
- 912 UL/ULS inlet nipple - optional M18 or UNF-thread (AN-8)

**Oil pump (inlet) (1) .....** thread M18 x 1,5 x 11

- ◆ **NOTE:** Suitable for use of a swivel joint. See Fig. 48.

Tightening torque of inlet line: .. 25 Nm (18.5 ft.lb)

**Fig. 44**


09123



## BRP-Rotax


### INSTALLATION MANUAL

**Oil pump inlet nipple (2):** outside dia ..... 13,2 mm (0.52 in.)  
slip-on length...max. 21 mm (0.83 in.)



**Fig. 45**  
00226

**Oil pump (inlet) (3) .....** thread 3/4-16 UNF (AN-8)  
Tightening torque of inlet line: .. 25 Nm (18.5 ft.lb)



**Fig. 46**  
09123

## BRP-Powertrain

### INSTALLATION MANUAL

#### Oil return

- **CAUTION:** The engine design is for a conventional, non-aerobatic, fixed wing tractor or pusher type configuration with the oil return port in the optimum position. With this consideration the engine is properly lubricated in all flight profiles. Aircraft that are not conventional (e.g. airship, gyrocopters, dive brake equipped aircraft etc.) that require engine load in steeply incline and decline angles (see also sec. 8.1, point 12) may require special lubrication considerations.

According to propeller configuration and oil system layout choose the appropriate connection for the oil return line.

Position **1** for tractor or position **2** for pusher configuration and connector-options (1), (2) and (5). See Fig. 47.

Option 1: - connection with slip-on connection (1):

hose nipple (3) ..... 10 DIN 7642  
outside dia. .... 13,5 mm (.53 in)  
slip-on length ..... max. 24 mm (max. .94 in)

Tightening torque of banjo bolt (4) M16x1,5x28: ..... 30 Nm (22 ft.lb)

Option 2 and 3:-connection with screw connection (2) or (5):

- connection with screw connection (2):

thread ..... 3/4-16 UNF (AN-8)

Tightening torque of oil return line: ..... 25 Nm (18.5 ft.lb)

Tightening torque of screw connection (2) M16x1,5: . 25 Nm (18.5 ft.lb)

- connection with screw connection (5):

thread ..... 3/4-16 UNF (AN-8)

Tightening torque of oil return line: ..... 25 Nm (18.5 ft.lb)

Tightening torque of banjo bolt (4) M16x1,5x28: ..... 30 Nm (22 ft.lb)




Fig. 47

08634

d04636

### 13.5.2) Oil tank

See Fig. 48 and 49.

The oil tank is furnished with 2 screw connections M18x1,5 and with a tapped hole (M10x1).

#### Connections for oil circuit (engine)

- Oil inlet (6) and outlet (7) via standard swivel joint and connecting bend (8):

2x connecting bend 90° (8)

outside dia. .... 12 mm (.47 in.)

slip-on length ..... max. 24 mm (.94 in.)

tightening torque ..... 25 Nm (18.5 ft.lb)

- Oil inlet (6) and outlet (7) via standard UNF thread (AN-8) (optional):

thread ..... 3/4-16 UNF (AN-8)


Tightening torque of oil inlet and outlet: ..... 25 Nm (18.5 ft.lb)

■ **CAUTION:** The oil tank cap is additionally marked with the term  
IN - oil inlet (6) from crank case  
OUT - oil outlet (7) to oil cooler/oil tank. See Fig.  
48.

1x venting nipple (9)

outside dia. .... 8 mm (.31 in.)

slip-on length ..... max. 15 mm (.59 in.)



d04055

### 13.6) Feasible position and location of the oil tank

See Fig. 50.

- The longitudinal axis  $z_3$  to be parallel to  $z$ -axis of the system of coordinates.  
Tolerated deviation of parallelism:  $\pm 10^\circ$


◆ NOTE: Above notice is valid for both planes.

The oil tank (1) has to be positioned in its  $z$ -axis such that the normal oil level (2) is always between 0 and -400 mm (-15.75 in.) on the  $z$ -axis .

◆ NOTE: The profile clamp of oil tank should be between 0 mm and -360 mm below the center line of the propeller shaft.

▲ WARNING: At higher location of the oil tank oil might trickle through clearances at bearings into crankcase during longer periods of engine stop. If fitted too low it might badly effect the oil circuit.

- Install the oil tank free of vibrations and not directly to the engine.
- Oil tank cover (3) and oil drain screw (4) to be easily accessible.



### 13.7) Feasible position and location of the oil cooler

See Fig. 50.

- On principle the oil cooler (5) has to be installed below the oil pump of the engine.

■ CAUTION: The oil cooler has to be installed with connections upwards i.e. in positive direction on z-axis. This will prevent an unintentional draining of the oil cooler at longer engine stop.

■ CAUTION: This will prevent an unintentional draining of the oil cooler at longer engine stop.

▲ WARNING: The oil cooler has to be planned and installed such that the specified operating temperatures are maintained and the max. values are neither exceeded nor fall below.

This state has to be warranted for "**hot day conditions**" too!

If need be, take appropriate measures like changing size of cooler, partial covering of cooler etc.

### 13.8) General notes on oil cooler

BRP-Powertrain offers for this engine an oil cooler (see Illustrated Parts Catalog, latest issue).

▲ WARNING: Certification of this cooler to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

■ CAUTION: The oil cooler has to be designed to dissipate approx. 8 kW (7,58 BTU/s) heat energy at take-off power.

◆ NOTE: From years of experience we recommend an oil cooler size of at least 160 cm<sup>2</sup> (25 in<sup>2</sup>), provided that air flow is adequate.

■ CAUTION: The oil cooler must not restrict oil flow. Test system as per sec 13.3.

### 13.9) Filling capacity

- Oil quantity **without** oil cooler and connecting lines min. 3 l (0,8 US gal) depending on the respective installation

#### Volume of oil tank

up to the MIN.-mark ..... approx. 2,5 l (0.66 US gal)

up to the MAX.-mark ..... approx. 3,0 l (0.8 US gal)

- Perform oil level check and add oil if necessary

**13.10) Purging of lubrication system**

See Fig. 51.

- Verify that oil tank connections are connected correctly and secured, and that the oil cooler (if fitted) is in the suction line (1) between the oil tank and the oil pump inlet. Verify that the oil tank is filled up to the maximum level (to the top of the flat portion of the dipstick). Additional oil (up to 0.5 litre) may be added to the tank for the purpose of this procedure.

■ **CAUTION:** Incorrectly connected oil lines to the oil tank or to the engine will result in severe engine damage.

- Disconnect oil line (2) at the oil tank connection.
- Place the free end (3) of the return oil line into a suitable container (4) below the engine.
- Plug open connection (5) at the oil tank with suitable air tight cap. See Fig. 51.
- Remove the spark plug connectors.
- For easier rotation of engine remove one spark plug from each cylinder.

■ **CAUTION:** Prevent entering of foreign substance through spark plug hole.

- Using a compressed air line, pressurize the oil tank through its breather connection (6) (on the neck of the tank). Adjust the compressor outlet regulator so that the air line pressure is between 0,4 (6 psi) and 1 bar (15 psi). Do not exceed 1 bar (15 psi).

◆ **NOTE:** Oil tank cover is not designed to hold pressure. Some air will escape.

▲ **WARNING:** Do not remove oil tank or cover before ensuring that air pressure has been completely released from the tank.

- The pressure in the oil tank has to be maintained during the following step.

■ **CAUTION:** It is possible to empty the oil tank and as a result introduce more air into the oil system. Pay attention to the oil level and fill tank as required.

- Turn the engine by hand in direction of normal rotation until the first pressure indication on the oil pressure gauge. Normally this will take approx. 20 turns. Depending on installation it may take up to 60 turns.

■ **CAUTION:** Do not use starter for this purpose. Fit propeller and use it to turn engine.

- Release the pressure from the oil tank.
- Un-block the oil return port on (5) the oil tank and reconnect the engine return oil line (2) to the oil return port on the oil tank.
- **CAUTION:** Ensure that the oil suction line (1) and engine oil return lines (2) are connected to the proper fittings on the oil tank. If the oil lines from the engine to the oil tank are incorrectly connected at the oil tank, severe engine damage may result.
- Replace spark plugs and restore aircraft to original operation condition.
- Residual oil will have accumulated in the crankcase, return it to the oil tank by following the oil check procedures in Operators Manual (or SI-27-1997 Oil level check for ROTAX engine type 912 and 914 (Series), current issue).
- Add oil to engine oil tank to bring the oil level up to the full mark on the dipstick.
- ▲ **WARNING:** Carefully check all lubrication system connections, lines and clamps for leaks and security.

### **13.11) Inspection for correct priming of hydraulic valve tappets**

See Fig. 52.


The subsequent check procedure describes the correct method to verify adequate priming of hydraulic valve tappets.

- **CAUTION:** Engine has reached operating temperatures here. Use appropriate safety equipment and clothing.
- Remove valve cover on cylinder 1.
- Turn crankshaft in direction of normal rotation so that the piston on cylinder 1 is on ignition top dead center (both valves are closed).
- Press on push rod side of rocker arm with a force (F) of about 70 N (15.0 lbf.) for about 3 sec. Approximate force can be verified with a fan belt tester. Repeat on other rocker arms.
- Check distance between rocker arm and valve contact surface. Max. allowable distance 0,5 mm (0.02 in.).
- Repeat on all other cylinders.
- **CAUTION:** If it is possible to push the valve tappets further than this limit, an additional engine run for about 5 min. at 3500 rpm after refitting the valve covers. To get the hydraulic valve tappets primed, this process can be repeated another 2 times.

### 13.12)Replacement of components

If a malfunction of hydraulic valve tappet should be found during this check of priming process, the relevant hydraulic valve tappet has to be replaced. The valve spring support has to be inspected for wear.

All work has to be performed in accordance with the relevant Maintenance Manual.



d04055



### **13.13)Data for optional components of oil system**

- oil radiator

See Fig. 53.

- weight: see section 8.

variants of connectors:

#### adaptor UNF (1):

thread ..... 3/4-16 UNF (AN-8)

Tightening torque:..... 22 Nm (195 in.lb) and Loctite 243.

Tightening torque of oil inlet and outlet:..... 25 Nm (18.5 ft.lb)

■ **CAUTION:** Counterhold on adaptor at installation of an oil line.

#### nipple (2):

outside dia ..... 13,2 mm (0.52 in.)

slip-on length ..... max. 21 mm (0.83 in.)

Tightening torque:..... 22 Nm (195 in.lb) and Loctite 243.

#### adaptor metric (3):

thread ..... M18x1,5

Tightening torque:..... 22 Nm (195 in.lb) and Loctite 243.

Tightening torque of oil inlet and outlet, bend socket or hose nipple:

..... 25 Nm (18.5 ft.lb)

■ **CAUTION:** Counterhold on adaptor at installation of an oil line.

#### angular tube (4) (90° nipple):

outside dia ..... 13,2 mm (0.52 in.)

slip-on length ..... max. 21 mm (0.83 in.)

Tightening torque:..... 22 Nm (195 in.lb) and Loctite 243.

#### bent socket (5) (90° socket):

outside dia ..... 12 mm (0.47 in.)

slip-on length ..... max. 24 mm (max. 0.94 in)

Tightening torque:..... 25 Nm (18.5 ft.lb)

#### hose nipple with union nut (6) (straight socket):



outside dia ..... 12 mm (0.47 in.)

slip-on length ..... max. 24 mm (max. 0.94 in)

Tightening torque:..... 25 Nm (18.5 ft.lb)

# BRP-Rotax

## INSTALLATION MANUAL



04910

**Fig. 53**

⌚B: LOCTITE 243

d04055

## **14) Fuel system**

### **14.1) Description of system**

See Fig. 54.

The fuel flows from the tank via a coarse filter/water trap (1) to the mechanical fuel pump (2), from the pumps fuel passes on via the fuel manifold (3) to the two carburetors.

Depending on the configuration of the engine the fuel lines from fuel pump to the carburetors are already installed by the manufacturer (optional on some engine).

The fuel system from tank to the inlet of engine-driven fuel pump has to be installed by the aircraft manufacturer.

Via the return line (5) surplus fuel flows back to the fuel tank and suction side of fuel system.

The fuel system includes the following items:


- tank
- coarse filter
- fine filter / water trap
- fuel shut off valve
- electrical fuel pump
- as well as the required fuel lines and connections

## BRP-Rotax

### INSTALLATION MANUAL

#### legend:

- (1) fine filter / water trap
- (2) mechanical fuel pump
- (3) fuel pressure control
- (4) feeding line from tank
- (5) return line to tank
- (6) 1 x check valve
- (7) electrical fuel pump



**Fig. 54**

07306

Only the following connections per Fig. 54 have to be established:

- Feeding lines to suction side of the mechanical fuel pump (2)
- lines from pressure side of the mechanical fuel pump to inlet of fuel manifold (3)
- Returnline from fuel pressure control to fuel tank.

d04056

## **14.2) Operating limits**

▲ **WARNING:** Design and layout of the fuel system has to warrant engine operation within the specified limits.

### **Fuel pressure:**

See Fig. 55.

max. .... 0,4 bar (5.8 psi.)  
min. .... 0,15 bar (2.2 psi.)  
normal ..... 0,3 bar (4.4 psi.)

▲ **WARNING:** Fuel pressure in excess of stated limit can lead to an override of the float valve with subsequent engine stop.

◆ **NOTE:** Readings of the fuel pressure are taken at the pressure gauge connection (6) on the fuel manifold (4). See Fig. 55.

The engine manufacturer recommends the use of an electrical auxiliary fuel pump, if this is not already required by airworthiness requirements.

The electrical auxiliary fuel pump is not just required in case of a malfunction or defect of the mechanical fuel pump, but also provides required fuel supply e.g. in case of vapour formation at high altitudes and temperatures.

◆ **NOTE:** If an electrical auxiliary fuel pump is installed, the whole fuel system has to be designed to warrant engine operation within the specified pressure limits.

■ **CAUTION:** The fuel pressure of an additional auxiliary fuel pump should not exceed 0,3 bar (4.4 psi.)

**14.3) Requirements of the fuel system****- Delivery rate:**

min. 35 l/h (8,2 US gal/h) of mechanical or electric fuel pump.

**- Fuel lines:** See Fig. 54.

▲ **WARNING:** Fuel lines have to be established to the latest requirements such as FAR or EASA by the aircraft manufacturer.

Secure fuel hoses with suitable screw clamps or by crimp connection.

■ **CAUTION:** For prevention of vapour locks, all the fuel lines on the suction side of the fuel pump have to be insulated against heat and fire in the engine compartment and routed at distance from hot engine components, without kinks and protected appropriately.

At very critical conditions e.g. problems with vapour formation the fuel lines could be routed in a hose with cold air flow.

**- Fuel filter:** See Fig. 54.

**Coarse filter:** on fuel tank as per valid certification

**Fine filter:** in the feed line from tank to the fuel pumps an additional fine filter with meshsize 0,1 mm (.004 in.) has to be provided.

The filter has to be controllable for service. A combination of filter/watertrap (gascolator) is recommended.

**- water trap:**

A suitable water trap must be installed at the lowest point of the fuel feed line.

**- Fuel temperature:**

In case of temperatures over 45 °C (113 °F) in the vicinity of fuel lines watch for vapour lock.

If you should encounter problems in this respect during the test period, than the affected components such as the supply line to the fuel pumps have to be cooled.

### 14.4) Connecting dimensions, location of joints and directives for installation

#### 14.4.1) fuel manifold

See Fig. 2, 3, 4 and 55.

- position of z4 axis of the fuel manifold:

◆ NOTE: Dimensions always from point of reference (P).

- return line to tank (5):  
outside dia. .... 7 mm (.28 in.)  
slip-on length: . max. 17 mm (.67 in.)
- pressure gauge connection (6):  
outside dia. .... 6 mm (.24 in.)  
slip-on length: . max. 17 mm (.67 in.)
- fuel pressure switch connection (9):  
thread ..... M10  
thread length: .. max. 9 mm (.35 in.)

Tightening torque: 15 Nm (135 in.lb) and Loctite 221.

■ CAUTION: At loosening or tightening of the banjo bolt (7) (tightening torque 10 Nm = 90 in.lb.) support the fuel manifold appropriately.

◆ NOTE: The connection nipple (5) is furnished with an orifice (8) (0,35 mm = 0.014 in.) essential for operation of the fuel system.

If the pressure gauge connection (6) is not used and a hose nipple (10) installed, the banjo bolt assy. (11) marked with a colour dot or marked "FUEL" is furnished with an orifice (12) (0,35 mm = 0.014 in.). This is essential for operation of the fuel system as it prevents a loss in fuel pressure.


02772

	coordinates [mm]		
	x axis	y axis	z axis
clamp block	-385,0	-50,0	ca.110

d04637

## BRP-Rotax

### INSTALLATION MANUAL



#### 14.4.2) Fuel pressure control

See Fig. 56 and 57.

- hose connection on fuel pump (1) inlet by slip-on joint. See fig. 56.

Fuel intake connection (9)

outside dia. .... 9 mm (.35 in.)

slip-on length: . max. 24 mm (.95 in.)

Fuel outlet connection (10)

outside dia. .... 6 mm (.24 in.)

slip-on length: . max. 24 mm (.95 in.)

- CAUTION: Ensure at installation of the supply line to fuel pump that no additional moments or load will rest on the pump!

- CAUTION: Utilize max. slip on length. Secure hoses with suitable screw clamps or crimp.

- hose connection on fuel pump (2) supplied with fire sleeved lines. See fig. 57.

Fuel intake connection (12):

fitting (15) ..... 9/16-18 UNF (AN-6)


Tightening torque: 15 Nm (135 in.lb)

Fuel outlet connection (13)

hose nipple (14) 3/4 DIN 7642


004056





**Fig. 56**

00537



**Fig. 57**

02064

### 14.4.3) Check valve

Specification:

opening pressure .....	0,1-0,15 bar (1,5 psi. - 2,2 psi.)
permitted pressure in reverse-biasing .....	2 bar (29 psi.)
burst pressure .....	5 bar (72,5 psi.)

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04056


## 15) Carburetor

See Fig. 58.

The carburetors on the standard engine are already attached by a flexible flange (and connecting hoses on the airbox). Only connections of the Bowden cable for pre-heating, choke and throttle have to be established.

It is recommended, to make the adjustment of the Bowden cable after engine installation has been completed, to ensure exact final adjustment.

▲ **WARNING:** The carburetor flange assembly has to carry the weight of the carburetor and intake system. Ensure that the screw of the clamp is positioned on the underside as supplied and the gap between the clamp plates is 8 mm (.31 in.).



**Fig. 58**

05794

### 15.1) Requirements on the carburetor

See Fig. 59.

The carburetors are positioned above the exhaust sockets. Below the carburetors one each drip tray (1) with a draining connection (2) is fitted which serves as a heat shield as well.

■ **CAUTION:** The float chamber venting lines (3) lines have to be routed into a ram-air and vacuum free zone or into the airbox, according to the requirements and release of BRP-Powertrain. See section 16. These lines must not be routed into the slipstream or down the firewall.

Pressure differences between intake pressure and pressure in the carburetor chambers may lead to engine malfunction due to incorrect fuel supply.

▲ **WARNING:** In the area of the float chamber the temperature limit of the fuel must not be exceeded.

If necessary install additional insulation or heat shields. Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

d04638

### 15.1.1) Drainage piping on airbox and drip trays

▲ **WARNING:** Connect drainage lines well, otherwise emerging fuel from a possible leakage could drip onto the exhaust system. **RISK OF FIRE!**

- The lines have to be routed such that in case of a damage the surplus fuel is drained off suitably.
- Route the lines without kinks and avoid tight bends
- Route the lines with a continuous decline.
- The lines have to be protected against any kind of blockage e.g. by formation of ice.

■ **CAUTION:** With closed or blocked leakage piping, fuel could end up on exhaust system. **RISK OF FIRE!**

■ **CAUTION:** The float chamber venting lines (3) lines have to be routed into a ram-air and vacuum free zone or into the airbox, according to the requirements and release of BRP-Powertrain. See section 16. These lines must not be routed into the slipstream or down the firewall.

Pressure differences between intake pressure and pressure in the carburetor chambers may lead to engine malfunction due to incorrect fuel supply.


#### Connecting nipple (2) for leakage line

outside dia. Ø 6 mm (1/4")

slip on length max. 17 mm (11/16")

# BRP-Powertrain

## INSTALLATION MANUAL



**Fig. 59**

08644

d04638

### 15.2) Connections for Bowden-cable actuation and limit load.


See Fig. 2, 3, 4, 60 and 61.

- centre position of carburetor socket (P1) of the respective carburetor:

◆ NOTE: All dimensions to point of reference (P)

- limit load on point of reference P2

■ CAUTION: The specified limit loads must never be exceeded.



	reference point P2
max. allowable forces (limit load) in (N) in x,y and z axis	60
max. allowable bending moments (limit load) in (Nm) in x,y and z axis	4

02028

	coordinates P1 [mm]		
carburetor for	x Achse	y Achse	z Achse
cylinder 1/3	-521	-180	25
cylinder 2/4	-553	180	25

09190

- connection (1) for air filter or intake silencer  
outside dia.: 50 mm (2 in.)  
slip-on length: 12 mm (.47 in.)
- connection for throttle actuation (2)  
connection on throttle lever: set screw M 5x12  
tightening torque: 4 Nm (35 in.lb)  
(suitable for 1,5 mm (.06 in.) steel wire)  
action travel: 65 mm (2 1/2")  
actuating force: min. 1,5 N (.3 lb)  
max. 8 N (1,8 lb)  
limit load: 20 N (4,5 lb)

◆ NOTE: Throttle opens by spring.


## BRP-Rotax

### INSTALLATION MANUAL

- connection for starting carb (choke) actuation (3)  
connection on choke lever: clamping nipple 6  
(suitable for 1,5 mm (.06 in.) steel wire)  
action travel: 23 mm ( $\frac{15}{16}$  ")  
actuating force: min. 10 N (2,2 lb)  
max. 45 N (10 lb)  
limit load: 100 N (22 lb)

#### Directive for choke actuation

The choke shaft (3) is marked (4). This mark has to point towards cable engagement (5).



**Fig. 61**


00541

### 15.3) Requirements on cable actuation

See Fig. 62.

The two throttles have to be controlled by two separate Bowden cables working synchronously.

Adjust the cables to a free travel of 1 mm (.04 in.).



▲ **WARNING:** With throttle lever not connected the carb will remain fully open. **The default position of the carburetor is full throttle!** Therefore never start engine without connecting throttle lever first.

◆ **NOTE:** Route Bowden cable in such a way that carb actuation will not be influenced by any movement of engine or air frame, thus possibly falsifying idle speed setting and carb synchronisation. Adjust Bowden cable such that throttle and choke can be fully opened and closed. Use Bowden cable with minimized friction so that the spring on the throttle can open the throttle completely. Otherwise increase pretension of spring by bending lever flap (1) or fit a stronger return spring, (2) or a cable with pull-push action would have to be used.

Secure the bowden cable sleeves (3) in the adjustment screws (4) (e.g. safety wire).

004057




**15.4) Requirements on the throttle lever**

See Fig. 63.

Adjustable positive stops for idle- and full throttle position are of course required.

These stops have to be designed such to render adjustability and to prevent overload of the idle stop on the carburetor.

The sketch (Fig. 63) depicts a feasible arrangement.



**Fig. 63**

09137

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04057

## **16) Air intake system**

See Fig. 64.

The intake system is determined essentially by the demands of engine and of the acceptable noise emission on the intake side. An airbox can be supplied by BRP-Powertrain as an option.

Performance data as specified and limits of operation can only be warranted by employment of the genuine ROTAX airbox.

■ **CAUTION:** The performance is given at ISA (15 °C) (59 F°) condition only. Engine is equipped with unchanged ROTAX tuned exhaust muffler system and air intake box.

If it will be necessary to use a different airbox or a modified genuine ROTAX airbox for reasons of installation the certification to the latest requirements such as FAR and EASA has to be conducted by the aircraft manufacturer.

◆ **NOTE:** If an airbox or genuine ROTAX airbox is retrofitted at a ROTAX 912 (A, F, UL) Series, a change in the carb jetting is required. See Illustrated Parts Catalog 912/914 chapter 22 and/or SB-912-044 "Use of the ROTAX supplied airbox", latest issue.

### **16.1) Operating limits**

#### **Fuel-mixture distribution:**

Low (cold) air temperature in the airbox is favourable for engine performance and to reduce knocking tendency at combustion.

The certification to the latest requirements such as FAR and EASA has to be conducted by the aircraft manufacturer.

■ **CAUTION:** Any changes on the air intake system (e.g. modification on the airbox etc.) can affect the flow rate in the air intake system and the fuel mixture ratio. In the course of certification the fuel mixture process must be proofed by a CO-measurement.

#### **CO-Measurement:**

CO-Emission ..... min. 3,0 % CO (wide open throttle (WOT);  
an rpm of min. 5200 1/min needs to be achieved)

Measurement in original configuration of aircraft e.g. with installed cowling.

Measured on each single cylinder. Measuring point is the same as the EGT-measurement. See section "Exhaust system".

## **16.2) Requirements on the air intake system**

▲ **WARNING:** Carb icing is a common reason for engine trouble. No implements are included in the supply volume for preheating of the intake air.

If an airbox of not ROTAX origin is used provisions for preheating the intake air have to be made to prevent formation of ice in the intake system.

Preheating of the intake air will result in performance loss because of the lower air density.

▲ **WARNING:** All items of the air intake have to be secured against loss.

▲ **WARNING:** The certification to the latest requirements such as FAR and EASA has to be conducted by the aircraft manufacturer.

### **Air intake socket (1) for fresh air or pre-heated air (intake side)**

outside dia.  $\varnothing$  ..... 60 mm (2 3/8")

slip-on length ..... max. 25 mm (1")

■ **CAUTION:** Utilize the full slip-on length on all connection. Secure hoses by suitable spring type clamp or screw clamp.

### **16.2.1) Requirements on the intake air ducting**

- max. length of ducting 500 mm (20 in.)
- min. inside dia. at least outside dia. of the intake socket on airbox
- min. mean bending radius 100 mm (4")

High engine performance needs air temperature as low as possible at air intake. Therefore the air filter should be located in a recess of the engine cowl or separated from warm air by baffles such that fresh air can be aspirated.

### **16.2.2) Airfilter**

■ **CAUTION:** A minimum flow rate of 6,23 m<sup>3</sup>/min. (220 cfm) has to be warranted for all conditions.

The pressure loss must not exceed 2 hPa.

▲ **WARNING:** Use only filter elements which will not tend to restrict the flow when in contact with water.

BRP-Powertrain offers an air filter as described below.

||

## BRP-Rotax

### INSTALLATION MANUAL

- ▲ **WARNING:** The certification to the latest requirement such as FAR and EASA has to be conducted by the aircraft manufacturer.

The following points should assist the aircraft manufacturer at the choice of a suitable filter:

- four fold cotton fabric
- surface covered with metal screen
- total filter area at least 1400 cm<sup>2</sup> (220 in<sup>2</sup>)
- a min. flow rate of 6,23 m<sup>3</sup>/min. (220 cfm)

#### 16.2.3) Airbox

See Fig. 64.

- volume at least 2,5 l (.66 US gal)
- outline dimension see Fig. 64

The airbox is furnished with 2 drain holes (1) at the lowest position possible.

The holes are necessary to drain fuel from flooding float chambers caused by badly closing float valve.

#### **Drainage lines:**

- ▲ **WARNING:** Connect draining lines without fail, otherwise emerging fuel could drip onto the exhaust system. **RISK OF FIRE!**
- The lines have to be routed such that in case of damage the surplus fuel is drained away suitably.
  - Route the lines without kinks and avoid narrow bends.
  - Route the lines with a continuous decline.
  - The lines have to be protected against any kind of blockage e.g. by formation of ice.
- **CAUTION:** With closed or blocked drainage bores fuel could flow into combustion chamber, possibly ruining the engine by hydraulic lock or emerging fuel could drip onto the exhaust system. **RISK OF FIRE!** .

# BRP-Powertrain

## INSTALLATION MANUAL

- **CAUTION:** The drainage lines (1) lines have to be routed into a ram-air and vacuum free or into the airbox, according to the requirements and release of BRP-Powertrain. See also section 15. These lines must not be routed into the slipstream. If the drainage lines of the airbox are connected with the drainage lines of the drip trays or the carburetors by a T-piece, these lines must not be routed down the firewall (drainage lines of the airbox separately are allowed).

Pressure differences between intake pressure and pressure in the carburetor chambers may lead to engine malfunction due to incorrect fuel supply.

Connecting nipple (1) of drainage line

outside dia.  $\varnothing$  ..... 6 mm (1/4")

slip-on length ..... max. 17 mm (11/16")

Provide connection to take readings of manifold pressure (2)

Provide connections for temperature sensor (3)

Outside diameter ..... 6 mm (.24 in.)

Slip-on length ..... 17 mm (.67 in.)

Connecting nipple (1) of float chamber venting lines

outside dia.  $\varnothing$  ..... 6 mm (1/4")

slip-on length ..... max. 17 mm (11/16")


- **CAUTION:** Utilize the complete slip-on length. Secure hoses by suitable screw clamps or by crimp connection.

- **CAUTION:** If the engine has been installed without employment of the optional ROTAX engine frame which includes also support of the airbox, than provide an appropriately support (5) for the airbox.

d04639

# BRP-Powertrain

## INSTALLATION MANUAL




- ◆ **NOTE:** Make sure that the air intake tubes of the airbox for fresh air and preheated air are connected correctly (see Fig. 64).
- ◆ **NOTE:** Fig. 64 shows the genuine ROTAX airbox.

### 16.3) Data for optional components of air intake system

- air filter

See Fig. 65.

- weight: see section 8.



09149

**Fig. 65**


d04058



# BRP-Powertrain

## INSTALLATION MANUAL

- airbox (configuration part no. 867756)  
See Fig. 66.
- weight: see section 8.



d04639

09174


**Fig. 66**

# INSTALLATION MANUAL

- See Fig. 66-1.

- weight: see section 8.

Neue Ausführung TNr. 667355  
New Version



d04639

Effectivity: 912 Series  
Edition 1 / Rev. 1

page 106  
May 01/2009

## 17) Electric system

See Fig. 67.

The engine is supplied with the wiring completed and ready to operate. Only the following connections to the aircraft have to be established.

- integrated generator
- external rectifier-regulator
- electronic modules
- electric starter
- start relay
- items conditional for operation like circuit breakers, ON-OFF switches, control lamps, relays, instrumentation and capacitors

### Optional extras

- external alternator (as option if the output of the integrated generator is inadequate)
- electric rev counter (accessory)
- consumer (battery)

### 17.1) Requirements on circuit wiring

- **CAUTION:** The connections have to be completed by the aircraft manufacturer in accordance to effective certification and wiring diagram (Fig. 67).

The electromagnetic compatibility (EMC) and electromagnetic interference (EMI) is greatly affected by the wiring and has to be checked for each installation.

- ▲ **WARNING:** The supply to the various consumers (e.g. battery) has to be protected adequately by fuses (consult wiring diagram). Using fuses too large may result in damage to electric equipment.

Under no circumstances route consumers cables (e.g. battery) side by side with ignition cable. Induction could cause problems.

- **CAUTION:** An excess-voltage protection has to be realized by the aircraft manufacturer in accordance to effective regulations.

- ▲ **WARNING:** The certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

- ▲ **WARNING:** Do not bend, kink, pinch or otherwise improperly stress the wiring harness. Use proper routing, clamping and strain relief on wiring harnesses.

### 17.1.1) Electromagnetic compatibility (EMC/EMI)

#### Electromagnetic interference (EMI) and lightning:

The engine complies with the EMI and lightning requirements per DO-160C, sections 18, 20-22 as noted in the following paragraphs.

#### Emission

Conducted RF Interference:

Narrowband and broadband emissions meet RTCA DO160C Section 21-1 Cat. B (AZ) except in the frequency range of 150kHz - 2MHz where emissions are up to 20dB higher than allowable limits.

Radiated RF Interference:

Narrowband and broadband emissions meet RTCA DO160C Section 21, Fig. 21-6 and 21-7, Cat. B except in the frequency range of 190kHz - 2MHz where emission are up to 35dB higher than allowable limits.

- ▲ **WARNING:** Consult the manufacturer if further interpretation is needed. These exceedances do not affect engine operation.

### 17.2) Wiring diagram

See Fig. 67.

#### Legend to wiring diagram (Fig. 67)

**Items 1-9, 24-25** are included in the standard volume of supply of the engine

**Items 10-14** are available as accessory

**Items 15-23** can't be supplied by BRP-Powertrain

- ▲ **WARNING:** The certification of items/components which are not included in the standard volume of supply of engine has to be conducted by the aircraft manufacturer to the latest requirements such as FAR or EASA.

- |       |  |
|-------|--|
| 1     | 2 electronic modules (A and B)                       |
| 2-3   | plug connection for ignition switch                  |
| 4     | integrated generator                                 |
| 5-6   | external regulator - rectifier with plug connections |
| 7     | electric starter                                     |
| 8-9   | starter relay with plug connection                   |
| 10-12 | external alternator with connections                 |
| 13    | electric rev-counter                                 |

# INSTALLATION MANUAL

- 
- The diagram illustrates a vehicle's electrical system with the following components and connections:
- 1**: Two relays, labeled A and B, connected to the battery.
  - 2**: Two terminals on the relays.
  - 3**: Two terminals on the relays.
  - 4**: An AC power source (alternator) connected to the system.
  - 5**: A fuse block containing fuses for G, G, R, B+, L, and C.
  - 6**: A set of five indicator lights connected to the fuse block.
  - 7**: The positive terminal of the battery.
  - 8**: A fuse on the main power line.
  - 9**: A switch (S) on the main power line.
  - 10**: A terminal connected to the battery and the alternator.
  - 11**: A fuse for the L (left) indicator light.
  - 12**: A fuse for the IG (ignition) circuit.
  - 13**: A terminal for the main power line.
  - 14**: A capacitor or filter component.
  - 15**: A set of three indicator lights.
  - 16**: A switch (S) on the main power line.
  - 17**: A switch (S) on the main power line.
  - 18**: A fuse for the L (left) indicator light.
  - 19**: A fuse for the main power line.
  - 20**: A fuse for the main power line.
  - 21**: A set of five indicator lights.
  - 22**: A terminal for the main power line.
  - 23**: A terminal for the main power line.
  - 24**: A terminal for the main power line.
  - 25**: A terminal for the main power line.
  - 26**: Two terminals on the relays.

Wiring symbols to DIN 40712, 40713, 40716 and 40719.

### 17.3) Technical data and connection of the electric components

#### 17.3.1) Integrated generator


See Fig. 68

Feeding wires (1) from the generator to rectifier-regulator on left side of ignition housing (see Fig. 68).

- 2 flexible cables, 1,5 mm<sup>2</sup> yellow (in shielding metal braid)
- length approx. 660 mm (26 in.) starting from ignition housing
- with on each plug socket 6,3 x 0,8 to DIN 46247

◆ NOTE: approx. 250W AC output at 5800 (r.p.m.)

For DC output in connection with rectifier-regulator see section 17.3.2.



#### 17.3.2) Rectifier-regulator


See Fig. 69/70.

- type: electronic full-wave rectifier regulator
- effective voltage:  $14 \pm 0,3 \text{ V}$  (from  $1000 \pm 250 \text{ r.p.m.}$ )
- current limit: max. 22 A
- max. permissible component temperature:  $+80 \text{ }^{\circ}\text{C}$  ( $176 \text{ }^{\circ}\text{F}$ ) (measured in area (1))
- weight: see section 8.

◆ NOTE: The performance specifications are given for optimal cooled components. If necessary, use a separate heat sink for the rectifier regulator.

# BRP-Powertrain

## INSTALLATION MANUAL



### Description of connections:

- G = yellow - from generator
- R = red - to battery, positive terminal
- +B = battery positive terminal
- L = warning lamp circuit
- C = control or field circuit

Fig. 69

08631

### Requirements for flawless operation of the rectifier-regulator

- body of regulator must be grounded with no resistance allowed
- the rectifier-regulator has to be protected by a slow blowing 25A fuse.
- wire size of the main circuit of at least 2,5 mm<sup>2</sup> (14 AWG)
- a capacitor (Fig. 67 Pos. (25)) of at least 22 000 µF / 25 V is necessary to protect the correct function of regulator and to flatten voltage. The regulator is not designed to store any electrical charge. If for any reason the battery or bus system is disconnected from the regulator while the engine is running (i.e. the master switch is shut off) the capacitor will safely absorb and dissipate the electrical charge produced by the generator. Otherwise the regulator would be damaged.

■ **CAUTION:** The voltage difference between battery and terminal **C** of regulator should be less than 0,2 V.

Use cables in this area as short as possible and with adequate cross section.

■ **CAUTION:** Never sever connection between terminal **C** and **+B** of regulator (e.g. by removal of a fuse) while the engine is running. Overvoltage and regulator damage can occur.

d04640

During engine stop break circuit between battery and terminal C to avoid discharge of battery! (see Fig. 67)

◆ **NOTE:** A charge-indicating lamp 3W/12V (Fig. 67, pos. (18)) may be fitted on the instrument panel.


### Current:

■ **CAUTION:** The graph current over engine speed has been determined and is valid only at the following conditions.

ambient temperature: ..... 20 °C (68 °F)

voltage: ..... permanent 13,5 V

tolerance: ..... max  $\pm 5\%$



**Fig. 70**

02500

### 17.3.3) Electronic modules

See Fig. 4 and 71.


Ambient temp. for the electronic modules (1): max. 80 °C (176 °F).

### 17.3.4) Ignition switches (MAG switch)

See Fig. 71, 72 and 73.

- type: two separate, suitable on-off switches (Fig. 67, pos. (15))
- switching voltage: min. 250 V
- switching current: min. 0,5 A

Wires from the ignition switches connect to the electronic module (see Fig. 71).



**Fig. 71**

02501

004059




## BRP-Rotax

### INSTALLATION MANUAL

- one each flexible wire 0,75 mm<sup>2</sup> (18 AMG), brown  
length approx. 35 mm (1 3/8") beginning at electronic module with  
one each plug socket and insulating sleeve 3,96 mm. At the new  
version the cable grommet and fasten connector are integrated in  
the 6-pole connector housing. See also SI-912-013, latest issue.

◆ **NOTE:** One each cable grommet (2) and flat pin terminal (3) are supplied loosely packed.

For correct assembly of the flat pin terminal strip the wire (4) and install the cable grommet in correct position and direction. Fix the flat pin terminal and the cable grommet with appropriate crimping pliers. The rubber grommet is held by the secondary crimp. Fit the flat pin terminal in the free position of the 6-pole connector housing until it is locked in place. Check for tight fit.



**Fig. 72**

08323

◆ **NOTE:** Faston connector and insulation sheath of the old version are available as spare part. See also SI-912-013, latest issue.

## BRP-Rotax


### INSTALLATION MANUAL

- Wire of top electronic module (marked "A") for ignition circuit A.
- Wire of bottom electronic module (marked "B") for ignition circuit B.

◆ **NOTE:** Ignition circuit A controls: top spark plugs of cylinder 1 and 2; lower spark plugs of cylinder 3 and 4.

Ignition circuit B controls: top spark plugs of cylinder 3 and 4; lower spark plugs of cylinder 1 and 2.

■ **CAUTION:** The electromagnetic compatibility (EMC) and electromagnetic interference (EMI) depends essentially on the wire used. See Fig. 73.



Min. section area: 2x 0,75 mm<sup>2</sup> (18 AMG) (shielded flexible cable, shielding braid on both ends grounded to prevent EMI (e.g specification MIL-27500/18).

No or insufficient shielded cables can cause engine shut-off due to electromagnetic and radio interference.

The metal base of each ignition switch must be grounded to aircraft frame to prevent EMI.

#### 17.3.5) Electric starter

See Fig. 74.

Wire from starter relay to the electric starter

- cross section of at least 16 mm<sup>2</sup> (6 AWG)
- output: 0,7 kW / 0,9 kW optional
- positive terminal (1): M6 screw (tightening torque 4 Nm (35 in.lb)) suitable for ring terminal to DIN 46225 ((MIL-T-7928) (PIDG) or equivalent)
- grounding: via engine block


■ **CAUTION:** Suitable for short starting periods only.

■ **CAUTION:** Max. 80 °C (176 °F) temperature range by the electric starter housing. Activate starter for max. 10 sec. (without interruption), followed by a cooling period of 2 min!

004059

## BRP-Rotax

### INSTALLATION MANUAL



00545

Fig. 74

#### 17.3.6) Starter relay

See Fig. 75.

- nominal voltage: 12 V
- control voltage: min. 6 V  
max. 18 V
- switching current: max. 75 A (permanent)  
max. 300 A (for 1 sec.)
- ambient temperature range:  
min. -40 °C (-40 °F)  
max. +100 °C (214 °F)
- weight: see section 8.
- current connections (1):  
M6 screw (tightening torque 4 Nm (35 in.lb)) suitable for ring  
terminals to DIN 46225
- control wiring (2):  
plug connector 6,3x0,8 suitable for spade connector to DIN 46247  
(MIL-T-7928) (PIDG) or equivalent)
- grounding: via housing

■ **CAUTION:** Activation of start relay limited to short duration. Over a period of 4 min. operation, the duty cycle is 25%.




Fig. 75

09169

d04059

### 17.3.7) External alternator (optional extra)

See Fig. 76, 77 and 78.

- output: max. 600 W DC at 6000 r.p.m.
- voltage: 14,2 V – 14,8 V
- ambient temperature range: min. - 30 °C (-22 °F)  
max. +90 °C (194 °F)
- weight: see section 8.

◆ NOTE: Voltage regulator is integrated in the alternator.

Feeding wiring to external alternator (1) located on the outside of propeller gear (see Fig. 76).

- plus terminal (2): M6 screw suitable for ring terminal to DIN 46225 (tightening torque 4 Nm (35 in.lb))
- grounding: via engine block mount bracket
- control wiring (field circuit) (3) and warning lamp circuit (4): via supplied standard plug (Sumitomo 6111-2568)





Fig. 77

04902

004059

## BRP-Rotax

### INSTALLATION MANUAL

#### Requirements for correct operation of the integrated rectifier-regulator:

- the rectifier-regulator has to be protected by a slow blowing fuse or circuit breaker. Fuse or circuit breaker rating must be determined by load, wire size and length.
- cross section of the main circuit at least 4 mm<sup>2</sup> (10 AWG)
- a capacitor (Fig. 67 Pos. (14)) of at least 22 000 µF / 25 V is necessary to flatten voltage.
- current:

■ **CAUTION:** The current over speed graph has been determined and is effective only at the following conditions:

ambient temperature: 20 °C (68 °F)

voltage: permanent 13,5 V

tolerance: ± 5%

◆ **NOTE:** The speed of the auxiliary generator is 1,24 or 1,32 times crankshaft speed or 3 times the prop speed.




Fig. 78

### 17.3.8) Connection of the electric rev-counter (tachometer)

See Fig. 67/79.

Feeding wiring to electric rev counter on left side of ignition housing.

- connections: 2 flexible cables 0,5 mm<sup>2</sup>, white/yellow and blue/yellow (in insulation wrap)
- length approx. 600 mm (24 in) starting from ignition housing.

◆ **NOTE:** BRP-Powertrain developed especially for this application a non-certified electric rev-counter. Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer. See also SI-13-1996, latest issue.

■ **CAUTION:** The graphs depicting output signals have been determined and are effective only at the following conditions.



Ambient temperature: 20 °C (68 °F)

Tolerance: ± 5%

The pick-up for the rev-counter generates one pulse per revolution. Pulse shape and pulse voltage as per recordings (oscillogram).

**speed 500 rpm (load 100 Ω)**

**speed 500 rpm (load 100 kΩ)**





**Fig. 79**

00219

**speed 6000 rpm (load 100 Ω)**

**speed 6000 rpm (load 100 kΩ)**



d04640

# BRP-Powertrain

## INSTALLATION MANUAL

### 17.3.9) Battery

See Fig. 67.

- **CAUTION:** To warrant reliable engine start use a battery of at least 16 Ah capacity.

### 17.3.10) Capacitor (Option electrical fuel pump)

See Fig. 67.

- **CAUTION:** To warrant reliable operation of the electrical fuel pump the use of capacitor of at least 22 000 µF / 25 V is necessary.


### 17.3.11) Easy start function on the electronic module (optional)

See Fig. 67 and 79/1.

In order to use the easy start function the relevant connections to the starter relays and ignition switch need to be made.

The start function can be used for aircraft, which have an engine start problem in cold conditions.

- ◆ **NOTE:** In addition also a modified fly wheel hub is offered, which aids improved starting.



d04640

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**

d04059



**18) Propeller drive**

The propeller in tractor or pusher arrangement has to be fitted on the propeller flange in accordance to current certification. As required utilize one of the three possible pitch circle diameters (P.C.D.) on the flange.

Certification of the propeller sizing and arrangement to the latest requirement such as FAR or EASA has to be conducted by the aircraft manufacturer.

▲ **WARNING:** Never run the engine without a propeller installed as engine would suffer severe damage by overspeeding.

Never fit propeller directly on crankshaft.

**18.1) Technical data**

See Fig. 80.

- direction of rotation  
of the prop flange: counter clockwise, looking towards face of  
flange
- attachment of propeller on prop shaft flange:
  - P.C.D 75 mm (2,95"): 6 bolt holes of 8 mm (.32 in.) dia
  - P.C.D 80 mm (3,15"): 6 bolt holes of 11,5 mm (.45 in.) dia
  - P.C.D 101,6 mm (4"): 6 bolt holes of 13 mm (.51 in.) dia.
  - hub diameter: 47 mm (1.85 in.)
- ratio of gear reduction: 2,2727 (50 Teeth/22 T)  
2,4286 (51 T/21 T)
- max. torque:
  - ROTAX 912 UL, A, F for i=2,2727: 238 Nm (176 ft.lb.) (at propeller)
  - ROTAX 912 UL, A, F for i=2,4286: 255 Nm (188 ft.lb.) (at propeller)
  - ROTAX 912 ULS, S for i=2,4286: 315 Nm (232 ft.lb.) (at propeller)
- max. moment of inertia :
  - normal between 1500 kgcm<sup>2</sup> (3.559 lb.ft.<sup>2</sup>) and 6000 kgcm<sup>2</sup> (14.238 lb.ft.<sup>2</sup>)
  - max. moment of inertia on propeller: 6000 kgcm<sup>2</sup> (14.238 lb.ft.<sup>2</sup>)
- max. permitted static  
out-of-balance on a prop: max. 0,5 gm (.043 lb.in.)
- max. extension of the propeller shaft: 120 mm (4.72 in.)

■ **CAUTION:** No modification of propeller shaft permitted.



# BRP-Rotax

## INSTALLATION MANUAL

### ◆ NOTE:

In the course of certification a vibration analysis of the whole system (engine, suspension, propeller etc.) should be done.

If there are no limits found in the technical literature, a max. of 0.1 IPS (inches per second) at 5000 rpm can be assumed.



d04060

## 19) Vacuum pump

### 19.1) Technical data

See Fig. 81 and 82

- drive via propeller gear
- location of the necessary connection on the crankcase:  
see Fig. 81 and 82

connection	coordinates		
	x axis mm	y axis mm	z axis mm
	-206,3	0	51,5

09191

- connections
  - thread size: M6
  - Effective thread length: max. 17 mm (9/16")
  - toothing: internal spline 20/40 SMS 1834 NA 14x1.27x30x12
- power input: max. 600 W

■ CAUTION: Pay attention to manufacturer's specifications.

◆ NOTE: Speed reduction from crankshaft to hydraulic governor is 1,724 or 1,842, i.e. the vacuum pump runs with 0,58 or 0,54 of engine speed.

▲ WARNING: Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.





Fig. 81

08322

004060

**BRP-Rotax**  
INSTALLATION MANUAL



**Fig. 82**

08328

## 20) Hydraulic governor for constant speed propeller

### 20.1) Technical data

See Fig. 83

◆ **NOTE:** See therefore also SB-912-052 "Installation / Use of governors for Rotax engine type 912 and 914", latest issue.



- drive via prop gear
- location of the necessary connection on the crankcase:  
see Fig. 83

connection	coordinates		
	x axis mm	y axis mm	z axis mm
	-206,3	0	51,5

09191

- connections  
mounting pad: AND20010  
thread size: M8  
Effective thread length: max. 14 mm (0.55 in.)  
toothing: internal spline 20/40 SMS 1834 NA 14x1.27x30x12  
direction of rotation of governor drive: clockwise, looking at mounting pad
  - power input: max. 600 W
  - operating pressure: max. 30 bar (435 psi.)
- **CAUTION:** Pay attention to manufacturer's specifications.
- ◆ **NOTE:** Speed reduction from crankshaft to hydraulic governor is 1,724 or 1,842, i.e. the vacuum pump runs with 0,58 or 0,54 of engine speed.

**BRP-Rotax**  
INSTALLATION MANUAL



**Fig. 83**

08179

## 21) Connections for instrumentation

These connections to be established in accordance to certification and/or national specifications.

The certification for connections and connection lines have to be conducted by the aircraft manufacturer to the latest requirements like FAR and EASA.


For notes regarding the electric rev-counter consult the section 17.

### 21.1) Sensor for cylinder head temperature

See Fig. 4, 84 and 85.


◆ **NOTE:** A direct reading of the coolant temperature is not provided for. The temperature sensor (1) is directly fitted into cylinder head i.e. a direct temperature reading of the cylinder head material is taken.

- location: in the cylinder head of the cylinders 2 and 3, see Fig. 4.
- connection: spade terminal 6,3x0,8 to DIN 46247
- grounding: via engine block
- graph of sensor resistance over temperature



04868

cylinder head	Axes		
	x axis mm	y axis mm	z axis mm
2	-200,0	241,0	-157,0
3	-387,0	-241,0	-157,0



■ **CAUTION:** The graph resistance over temperature has been determined, and is effective at the following conditions only.

ambient temperature: 20 °C (68 °F)  
tolerance: ± 10%

### 21.2) Sensor for oil temperature

See Fig. 86 and 87

- location: oil pump housing
- marking (2): marked with "TO" (temperature oil) on oil pump flange

■ **CAUTION:** To avoid any mix-up with indication wiring, mark this particular cable also with "TO".

point of support	Axes		
	x axis	y axis	z axis
	mm	mm	mm
	-115	46	-150

04869

- position of the temperature sensor (1) on the oil pump flange:
- connection of sensor wiring: spade terminal 6,3 x 0,8 to DIN 46247
- grounding: via engine block
- graph of sensor resistance over temperature

■ **CAUTION:** The graph resistance over temperature has been determined, and is effective at the following conditions only.

ambient temperature: 20 °C (68 °F)

tolerance: ± 10%

BRP-Powertrain offers a non-certified temperature indicating instrument. Refer to Illustrated Parts Catalog, latest issue.

▲ **WARNING:** Certification to the latest requirements such as FAR of EASA has to be conducted by the aircraft manufacturer.




Fig. 86

00226




Fig. 87

00227

d04641



### 21.3) Oil pressure sensor

See Fig. 88 and 89.

- location: oil pump housing
- wiring connection for instrument:


The sensor cable is approx. 3 m long and has 3 leads. The **Black** lead is not to be connected and has no function. The **Red** lead from the sensor has to be connected to the positive bus via a fuse or circuit breaker. The **White** lead (output signal) has to be connected directly to the instrument. See also the relevant instructions of the instrument supplier/aircraft manufacturer for correct connection and wiring.

◆ **NOTE:** The sensor cable can be modified in its length according to the installation situation, e.g. shortened or extended. For extension an appropriate, commercially available cable can be used. A resistance cable or similar is not necessary.

- wire gauge: stranded wire, 0,5 mm<sup>2</sup> (AWG 20)
- cable length: 3 m (118 in.)
- operating temperature range: min.: - 40 °C (-40 °F)  
max.: + 125 °C (+ 257 °F)
- grounding: via engine block/airframe ground
- output signal: In contrary to the oil pressure sensor offered up to now, which was providing the signal on the basis of a sensor resistance variation, the new oil pressure sensor (1) operates on basis of a current variation. This has to be taken into account for the selection of the appropriate cockpit instrument.

■ **CAUTION:** The graph current over pressure has been determined, and is effective at the following conditions only (see fig. 89).

Fig. 88




ambient temperature: 20 °C (68 °F)

tolerance: max. ± 3%

- tightening torque: 15 Nm (98 in.lb) and  
LOCTITE 243

Fig. 89



d04641

08379

08442

As the instruments need a separate power supply and a different design for the electrical oil pressure sensor, the resistance type instrument (type VDO), which was supplied by BRP-Powertrain up to now, is not suitable anymore. Suitable instruments are offered by various instrument manufacturers (e.g. ROAD or Aviasport).


▲ **WARNING:** Certification to the latest requirements such as FAR of EASA has to be conducted by the aircraft manufacturer.

### 21.4) Mechanical rev counter (tach drive):

See Fig. 90 and 91

- location: ignition housing (1)
- direction of rotation of the rev counter shaft (2): clockwise, see figure below.
- position of rev counter drive:
- installation dimensions: see figures above.

04871	Axes		
point of engagement	x axis mm	y axis mm	z axis mm
P4	-465	87	-160



05483

Fig. 90




Fig. 91

00562

- reduction ratio:  $i = 4$  i.e. 1/4 of engine speed

## 21.5) Monitoring of the intake manifold pressure


See Fig. 92.

### Connection nipple (1) to measure manifold pressure:

outside dia.  $\varnothing$  ..... 6 mm (1/4")

slip-on length. max. 17 mm (11/16")

- **CAUTION:** Utilize the total slip-on length on all joints. Secure hose by suitable screw clamps or crimp connection.



**Fig. 92**

02051

- ▲ **WARNING:** Protective covering to be utilized for transport and at engine installation only. If connection for pressure reading is not employed it has to suitably plugged. New style compensating tubes have plugged this connection by a screw M3.5x6 (2).
- **CAUTION:** Flawless operation of the indicating instrument needs the installations of a water trap between engine and instrument for the fuel condensate.


**BRP-Powertrain**  
INSTALLATION MANUAL

### 21.6) Air temperature in the airbox (optional)

See Fig. 93.

To take air temperature readings in the airbox a connection is provided. This connection is closed on the standard engine by a plug screw.

- connection:    thread M6  
                     thread length approx. 9 mm (3/8")



08647  
**Fig. 93**

## **22) Preparations for trial run of engine**

▲ **WARNING:** Prior to engine start and operation review all instructions stated in the Operators Manual.

**Conduct test run:**

See Operators Manual 912 section 10.3

**Verification of the throttle lever detent for max. continuous power:**

Performance check in accordance with Operators Manual.

If nominal performance won't be reached or is in excess of, examination of the installation and engine will be necessary. Consult Maintenance Manual 912.

■ **CAUTION:** Don't conduct any test flights before fault has been traced and found.

**BRP-Rotax**  
INSTALLATION MANUAL

**NOTES**





Motornummer / Engine serial no.

Flugzeugtype / Type of aircraft

Flugzeugkennzeichen / Aircraft registration no.

ROTAX® Vertriebspartner

ROTAX® authorized distributor

**[www.rotax-aircraft-engines.com](http://www.rotax-aircraft-engines.com)**